

# AC Servo Motor Drivers



## Pulse Input Type/Positioning Type p. 13

Incremental Type  
LECSA Series



## Pulse Input Type p. 13

Absolute Type  
LECSB Series



## CC-Link Direct Input Type p. 13

Absolute Type  
LECSA Series

CC-Link



## SSCNET III Type p. 13

Absolute Type  
LECSS Series



## Pulse Input Type/Positioning Type p. 13

Absolute Type  
LECSB-T Series



Safety function STO available

## CC-Link Direct Input Type p. 13

Absolute Type  
LECSA-T Series

CC-Link



## New Network Card Type p. 13

Absolute Type  
LECSN-T Series



EtherCAT  
EtherNet/IP

Safety function STO available



## SSCNET III/H Type p. 13

Absolute Type  
LECSS-T Series



Safety function STO available



## MECHATROLINK-II Type p. 39

Absolute Type  
LECYM Series

MECHATROLINK-II



Safety function STO available

## MECHATROLINK-III Type p. 39

Absolute Type  
LECYU Series


MECHATROLINK-III



Safety function STO available

# LECS□/LECS□-T/LECY□ Series

# AC Servo Motor Drivers



## LECS□/LECS□-T/LECY□ Series List

Series	Compatible motor				Control method			Application/Function		Compatible option
	100 W	200 W	400 W	750 W	Positioning <sup>*1</sup>	Pulse	Network direct input	Synchronous <sup>*2</sup>	Pushing operation <sup>*4</sup>	Setup software
Incremental Type	<b>LECSA</b> (Pulse input type/ Positioning type)	●	●	●	Up to 7 points	●				LEC-MRC2
	<b>LECSB</b> (Pulse input type)	●	●	●		●				LEC-MRC2
	<b>CC-Link</b> <b>LECSB</b> (Pulse input type)	●	●	●						LEC-MRC2
	<b>LECSB</b> (Pulse input type)	●	●	●	Up to 255 points		CC-Link Ver. 1.10			LEC-MRC2
	<b>CC-Link</b> <b>LECSB</b> (Pulse input type)	●	●	●						LEC-MRC2
	<b>LECSB</b> (Pulse input type)	●	●	●						LEC-MRC2
	<b>CC-Link</b> <b>LECSB</b> (Pulse input type)	●	●	●	Up to 255 points		CC-Link Ver. 1.10			LEC-MRC2
	<b>LECSB</b> (Pulse input type)	●	●	●						LEC-MRC2
	<b>SSCNET III</b> <b>LECSB</b> (Pulse input type)	●	●	●			SSCNET III	● <sup>*2</sup>	● <sup>*4</sup>	LEC-MRC2
	<b>LECSB-T</b> (Pulse input type/ Positioning type)	●	●	●	Up to 255 points	●			● <sup>*4</sup>	LEC-MRC2
Absolute Type	<b>CC-Link</b> <b>LECSB-T</b> (Pulse input type/ Positioning type)	●	●	●						LEC-MRC2
	<b>CC-Link</b> <b>LECSB-T</b> (Pulse input type)	●	●	●	Up to 255 points		CC-Link Ver. 1.10			LEC-MRC2
	<b>CC-Link</b> <b>LECSB-T</b> (Pulse input type)	●	●	●						LEC-MRC2
	<b>PROFINET</b> EtherCAT <sup>®</sup> EtherNet/IP <sup>™</sup> <b>LECSN-T</b> (Network card type)	●	●	●	Up to 255 points <sup>*5</sup>		PROFINET EtherCAT EtherNet/IP <sup>™</sup>			LEC-MRC2
	<b>SSCNET III/H</b> <b>LECSN-T</b> (Network card type)	●	●	●			SSCNET III/H	● <sup>*2</sup>	● <sup>*4</sup>	LEC-MRC2
	<b>MECHATROLINK-II</b> <b>LECSN-T</b> (Network card type)	●	●	●			MECHATROLINK-II	● <sup>*3</sup>		SigmaWin+ <sup>™</sup>
	<b>MECHATROLINK-II</b> <b>LECSN-T</b> (Network card type)	●	●	●			MECHATROLINK-II	● <sup>*3</sup>		SigmaWin+ <sup>™</sup>
	<b>MECHATROLINK-III</b> <b>LECSN-T</b> (Network card type)	●	●	●			MECHATROLINK-III	● <sup>*3</sup>		SigmaWin+ <sup>™</sup>
<b>LECYM</b> (Network card type)	●	●	●						LEC-MRC2	
<b>LECYU</b> (Network card type)	●	●	●						LEC-MRC2	

\*1 For positioning types, the settings need to be changed in order to use the max. set values. Setup software (MR Configurator2<sup>™</sup>) LEC-MRC2 is required.

\*2 Available when a Mitsubishi motion controller is used as the master

\*3 Available when a motion controller is used as the master

\*4 The LECSB2-T is only applicable when the control method is positioning. The point table is used to set the pushing operation settings.

To set the pushing operation settings, an additional dedicated file (pushing operation extension file) must be downloaded separately to be used with the setup software (MR Configurator2<sup>™</sup>: LEC-MRC2□). Please download this dedicated file from the SMC website: <https://www.smcworld.com>  
When selecting the LECSB or LECSB2-T, combine it with a master station (such as the Simple Motion module manufactured by Mitsubishi Electric Corporation) which has a pushing operation function.


\*\* For customer-provided PLC and motion controller setting and usage instructions, confirm with the retailer or manufacturer.

\*5 Only supports PROFINET and EtherCAT

## Gain adjustment using auto tuning


### Auto-tuning function

- Controls the difference between the command value and the actual action



### Vibration suppression control function

- Automatically suppresses low-frequency machine vibrations (1 to 100 Hz)



# AC Servo Motor Driver

## With display setting function

### One-touch adjustment button


One-touch servo adjustment

### Display

Display the monitor, parameter and alarm.

### Settings

Set parameters and monitor display, etc., with push buttons.




**LECSA**

### Display

Display the monitor, parameter and alarm.

### Settings

Set parameters and monitor display, etc., with push buttons.



(With the front cover open)


**LECSB**

### Display

Display the communication status with the driver, the alarm and the point table No.

### Settings

Control Baud rate, station number and the occupied station count.



(With the front cover open)


**LECSA**

### Display

Display the communication status with the driver and the alarm.

### Settings

Switches for selecting axis and switching to the test operation



(With the front cover open)


**LECSB**

### Display

Display the monitor, parameters, and alarm.

### Settings

Set the parameters, monitor display, etc., with push buttons.



(With the front cover open)


**LECSB-T**

### Display

Display the communication status with the driver, the alarm, and the point table no.

### Settings

Control the Baud rate, station number, and the occupied station count.



(With the front cover open)


**LECSA-T**

### Display

Display the communication status with the driver and the alarm.

### Settings

Switches for axis setting, control axis deactivation, switching to the test operation, etc.




**LECS2-T**

### Display

Display the communication status with the driver and the alarm.

### Settings

Switches for axis setting, switching to the test operation, etc.




**LECSN-T**

### Settings

Switches for station address, communication speed, number of transmission bytes, etc.

### Display

Display the driver status and alarm.




**LECYM**

### Settings

Switches for station address, number of transmission bytes, etc.



### Display

Display the driver status and alarm.



**LECYU**

# System Construction



# System Construction

## Absolute encoder compatible **LECSC Series** (CC-Link direct input type)

Provided by customer

### Power supply

Single phase 100 to 120 VAC (50/60 Hz)  
200 to 230 VAC (50/60 Hz)  
Three phase 200 to 230 VAC (50/60 Hz)

Option Page 36  
**Regeneration option**  
LEC-MR-RB-□

### Motor cable


Standard cable	Robotic cable
LE-CSM-S□□	LE-CSM-R□□

### Lock cable

Standard cable	Robotic cable
LE-CSB-S□□	LE-CSB-R□□

Provided by customer

Power supply for lock  
24 VDC



Electric actuator

Slider type  
**LEF Series**

High rigidity slider type

**LEJ Series**

Rod type

**LEY Series**

Guide rod type

**LEYG Series**

### Encoder cable

Standard cable	Robotic cable
LE-CSE-S□□	LE-CSE-R□□


Main circuit power supply connector (Accessory) Page 22

Control circuit power supply connector (Accessory) Page 22

Motor connector (Accessory) Page 22

Battery (Accessory) (LEC-MR-J3BAT) Page 38

Driver



USB cable Page 38  
LEC-MR-J3USB

Option

Setup software Page 37  
(MR MR Configurator2™)  
LEC-MRC2□



PC

RS-422 communication

CC-Link connector\*1 (Accessory)

Option Page 34

I/O connector  
LE-CSNA

or  
I/O cable Page 35  
LEC-CSNA-1

Provided by customer

PLC (CC-Link master unit)

Power supply for I/O signal  
24 VDC



\*1 Product number: K05A50230600 manufactured by Mitsubishi Electric System & Service Co., Ltd.

## Absolute encoder compatible **LECSS Series** (SSCNET III type)

Provided by customer

### Power supply

Single phase 100 to 120 VAC (50/60 Hz)  
200 to 230 VAC (50/60 Hz)  
Three phase 200 to 230 VAC (50/60 Hz)

Option Page 36  
**Regeneration option**  
LEC-MR-RB-□

### Motor cable


Standard cable	Robotic cable
LE-CSM-S□□	LE-CSM-R□□

### Lock cable

Standard cable	Robotic cable
LE-CSB-S□□	LE-CSB-R□□

Provided by customer

Power supply for lock  
24 VDC



Electric actuator

Slider type  
**LEF Series**

High rigidity slider type

**LEJ Series**

Rod type

**LEY Series**

Guide rod type

**LEYG Series**

### Encoder cable

Standard cable	Robotic cable
LE-CSE-S□□	LE-CSE-R□□


Main circuit power supply connector (Accessory) Page 22

Control circuit power supply connector (Accessory) Page 22

Motor connector (Accessory) Page 22

Battery (Accessory) (LEC-MR-J3BAT) Page 38

Driver



USB cable Page 38  
LEC-MR-J3USB

Option

Setup software Page 37  
(MR MR Configurator2™)  
LEC-MRC2□



PC

Option  
I/O connector Page 34  
LE-CSNS

or  
I/O cable Page 35  
LEC-CSNS-1

Option Page 35  
SSCNET III  
optical cable  
LE-CSS-□

Provided by customer

PLC (Positioning unit/  
Motion controller)

Power supply for I/O signal  
24 VDC



# System Construction

## Absolute encoder compatible **LECSB-T Series** (Pulse input type/Positioning type)

### Provided by customer

#### Power supply

Single phase 200 to 240 VAC (50/60 Hz)  
Three phase 200 to 240 VAC (50/60 Hz)

Option Page 36  
**Regeneration option**  
LEC-MR-RB-□

Motor cable Page 34  
Standard cable Robotic cable  
LE-CSM-S□□ LE-CSM-R□□

Lock cable Page 34  
Standard cable Robotic cable  
LE-CSB-S□□ LE-CSB-R□□

### Provided by customer

Power supply for lock  
24 VDC



#### Electric actuator

Slider type  
**LEF Series**  
High rigidity slider type  
**LEJ Series**  
Rod type  
**LEY Series**  
Guide rod type  
**LEYG Series**




Encoder cable Page 34  
Standard cable Robotic cable  
LE-CSE-S□□ LE-CSE-R□□

Main circuit power supply connector (Accessory) Page 23

Control circuit power supply connector (Accessory) Page 23

Motor connector (Accessory) Page 23

Battery (Accessory) Page 38  
(LEC-MR-BAT6V1SET)



USB cable Page 38  
LEC-MR-J3USB

Option  
Setup software Page 37  
(MR MR Configurator2™)  
LEC-MRC2□



PC

Analogue monitor output  
RS-422 communication

Option  
STO cable (3 m) Page 38  
LEC-MR-D05UDL3M

Option  
I/O connector Page 34  
LE-CSNB

or  
I/O cable Page 35  
LEC-CSNB-1

Provided by customer

PLC (Positioning unit)  
Power supply for I/O signal  
24 VDC



## Absolute encoder compatible **LECSC-T Series** (CC-Link direct input type)

### Provided by customer

#### Power supply

Single phase 200 to 230 VAC (50/60 Hz)  
Three phase 200 to 230 VAC (50/60 Hz)


Option Page 36  
**Regeneration option**  
LEC-MR-RB-□

Motor cable Page 34  
Standard cable Robotic cable  
LE-CSM-S□□ LE-CSM-R□□

Lock cable Page 34  
Standard cable Robotic cable  
LE-CSB-S□□ LE-CSB-R□□

### Provided by customer

Power supply for lock  
24 VDC



#### Electric actuator

Slider type  
**LEF Series**  
High rigidity slider type  
**LEJ Series**  
Rod type  
**LEY Series**  
Guide rod type  
**LEYG Series**




Encoder cable Page 34  
Standard cable Robotic cable  
LE-CSE-S□□ LE-CSE-R□□

Main circuit power supply connector (Accessory) Page 24

Control circuit power supply connector (Accessory) Page 24

Motor connector (Accessory) Page 24

Battery (Accessory) Page 38  
(LEC-MR-J3BAT)



USB cable Page 38  
LEC-MR-J3USB

Option  
Setup software Page 37  
(MR MR Configurator2™)  
LEC-MRC2□



PC

RS-422 communication

CC-Link connector\*1 (Accessory)

Option  
I/O connector Page 34  
LE-CSNA

or  
I/O cable Page 35  
LEC-CSNA-1

Provided by customer

PLC (CC-Link master unit)  
Power supply for I/O signal  
24 VDC



# System Construction

## Absolute encoder compatible **LECSN-T Series** (Network card type)

### Provided by the customer

#### Power supply

Single phase 200 to 240 VAC (50/60 Hz)  
Three phase 200 to 240 VAC (50/60 Hz)

#### Option Page 36

Regeneration option  
Part no.: **LEC-MR-RB-□**

#### Motor cable Page 34

Standard cable	Robotic cable
<b>LE-CSM-S-□□</b>	<b>LE-CSM-R-□□</b>

#### Lock cable Page 34

Standard cable	Robotic cable
<b>LE-CSB-S-□□</b>	<b>LE-CSB-R-□□</b>

### Provided by the customer

#### Power supply for lock

24 VDC

#### Electric actuator

Slider type  
**LEF Series**

High rigidity slider type  
**LEJ Series**

Rod type  
**LEY Series**

Guide rod type  
**LEYG Series**

#### Encoder cable Page 34

Standard cable	Robotic cable
<b>LE-CSE-S-□□</b>	<b>LE-CSE-R-□□</b>


● Main circuit power supply connector (Accessory) Page 23

Driver

◎ Option

● USB cable Page 38  
Part no.: **LEC-MR-J3USB**

● Setup software Page 37  
(MR Configurator2™)  
Part no.: **LEC-MRC2-□**



◎ Option

● Network card Page 36  
Part no.: **LEC-S-N-□**

◎ Option Page 38

● STO cable (3 m)  
Part no.: **LEC-MR-D05UDL3M**

● Control circuit power supply connector (Accessory) Page 34

● Motor connector (Accessory) Page 23


◎ Option  
● I/O connector Page 34  
Part no.: **LE-CSNS**  
or  
I/O cable Page 35  
Part no.: **LEC-CSNS-1**

Provided by the customer

Page 38  
● Battery (Accessory)  
Part no.: **(LEC-MR-BAT6V1SET-A)**

PLC (Positioning unit)

Power supply for I/O signal  
24 VDC



\* The LECSN2-T□ cannot be used with the LEC-MR-SETUP221□.

## Absolute encoder compatible **LECSS-T Series**



### Provided by customer

#### Power supply

Single phase 200 to 240 VAC (50/60 Hz)  
Three phase 200 to 240 VAC (50/60 Hz)

#### Option Page 36

Regeneration option  
**LEC-MR-RB-□**

#### Motor cable Page 34


Standard cable	Robotic cable
<b>LE-CSM-S-□□</b>	<b>LE-CSM-R-□□</b>

#### Lock cable Page 34

Standard cable	Robotic cable
<b>LE-CSB-S-□□</b>	<b>LE-CSB-R-□□</b>

### Provided by customer

Power supply for lock  
24 VDC



#### Electric actuator

Slider type  
**LEF Series**

High rigidity slider type  
**LEJ Series**

Rod type  
**LEY Series**

Guide rod type  
**LEYG Series**

Page 23  
● Main circuit power supply connector (Accessory)

Driver

◎ Option

Page 38  
● USB cable  
**LEC-MR-J3USB**

● Setup software Page 37  
(MR Configurator2™)  
**LEC-MRC2-□**



◎ Option  
● I/O connector Page 34  
**LE-CSNS**  
or  
I/O cable  
**LEC-CSNS-1** Page 35


◎ Option  
● STO cable (3 m) Page 38  
**LEC-MR-D05UDL3M**

● Control circuit power supply connector (Accessory) Page 23

● Motor connector (Accessory) Page 23

Page 38  
● Battery (Accessory)  
**(LEC-MR-BAT6V1SET)**

◎ Option Page 35  
● SSCNET III optical cable  
**LE-CSS-□**



Provided by customer

PLC (Positioning unit/Motion controller)

Power supply for I/O signal  
24 VDC



\* The LECSS2-T□ cannot be used with the LEC-MR-SETUP221□.



# System Construction

## Absolute encoder compatible **LECYM Series** MECHATROLINK -II type

### Provided by customer

#### Power supply

Single phase 200 to 230 VAC (50/60 Hz)  
Three phase 200 to 230 VAC (50/60 Hz)

### Provided by customer

#### External regenerative resistor

\* If an external regenerative resistor is required, it should be provided by the customer. For external regenerative resistor selection, refer to the compatible actuator catalogue.

### Motor cable

Standard cable	Robotic cable
LE-CYM-S□-A-□	LE-CYM-R□-A-□

### Motor cable for lock option

Standard cable	Robotic cable
LE-CYB-S□-A-□	LE-CYB-R□-A-□

### Provided by customer

#### Power supply for lock




#### Electric actuator

Slider type  
**LEF Series**


High rigidity slider type  
**LEJ Series**

Guide rod type  
**LEY/LEYG Series**

### Main circuit power supply connector (Accessory)




### Motor connector (Accessory)



### Encoder cable

Standard cable	Robotic cable
LE-CYE-S□A	LE-CYE-R□A

### Driver



Option

### MECHATROLINK II cable

LE-CYM-□

### 2nd driver

### Provided by customer

### PLC (Positioning unit/Motion controller)

#### Power supply for I/O signal

24 VDC




Option

### USB cable

LEC-JZ-CVUSB

### Setup software

(SigmaWin+™)  
Please download it via our website.



PC

### I/O connector

LE-CYNA

or

I/O cable

LEC-CSNA-1

Page 46

### Cable for safety function device (3 m)

LEC-JZ-CVSAF

\* Order the USB cable (Part no.: LEC-JZ-CVUSB) separately to use this software.

## Absolute encoder compatible **LECYU Series** MECHATROLINK -III type

### Provided by customer

#### Power supply

Single phase 200 to 230 VAC (50/60 Hz)  
Three phase 200 to 230 VAC (50/60 Hz)

### Provided by customer

#### External regenerative resistor

\* If an external regenerative resistor is required, it should be provided by the customer. For external regenerative resistor selection, refer to the compatible actuator catalogue.

### Motor cable

Standard cable	Robotic cable
LE-CYM-S□-A-□	LE-CYM-R□-A-□

### Motor cable for lock option

Standard cable	Robotic cable
LE-CYB-S□-A-□	LE-CYB-R□-A-□

### Provided by customer

#### Power supply for lock




#### Electric actuator

Slider type  
**LEF Series**


High rigidity slider type  
**LEJ Series**

Guide rod type  
**LEY/LEYG Series**

### Main circuit power supply connector (Accessory)



### Motor connector (Accessory)



### Encoder cable

Standard cable	Robotic cable
LE-CYE-S□A	LE-CYE-R□A

### Driver



Option

### MECHATROLINK III cable

LE-CYU-□

### 2nd driver

### Provided by customer

### PLC (Positioning unit/Motion controller)

#### Power supply for I/O signal

24 VDC




Option

### USB cable

LEC-JZ-CVUSB

### Setup software

(SigmaWin+™)  
Please download it via our website.



PC

### I/O connector

LE-CYNA

or

I/O cable

LEC-CSNA-1

Page 46

### Cable for safety function device (3 m)

LEC-JZ-CVSAF

\* Order the USB cable (Part no.: LEC-JZ-CVUSB) separately to use this software.

# AC Servo Motor Driver

LECS□ Series

Power supply voltage 100 to 120 VAC  
200 to 230 VAC

Motor capacity 100/200/400 W

Incremental Type

## LECSA Series (Pulse input type/Positioning type)



- Up to 7 positioning points by point table
- Input type: Pulse input
- Control encoder: Incremental 17-bit encoder (Resolution: 131072 p/rev)
- Parallel input: 6 inputs  
output: 4 outputs

## LECSB Series (Pulse input type)



- Input type: Pulse input
- Control encoder: Absolute 18-bit encoder (Resolution: 262144 p/rev)
- Parallel input: 10 inputs  
output: 6 outputs

## LECS C Series (CC-Link direct input type)



- Position data/speed data setting and operation start/stop
- Positioning by up to 255 point tables (when 2 stations are occupied)
- Up to 32 drivers can be connected (when 2 stations are occupied) with CC-Link communication.
- Applicable Fieldbus protocol: CC-Link (Ver. 1.10, Max. communication speed: 10 Mbps)
- Control encoder: Absolute 18-bit encoder (Resolution: 262144 p/rev)

CC-Link

Absolute Type

## LECSS Series (SSCNET III type)



- Compatible with Mitsubishi Electric's servo system controller network
- Reduced wiring and SSCNET III optical cable for one-touch connection
- The SSCNET III optical cable provides enhanced noise resistance.
- Up to 16 drivers can be connected with SSCNET III communication.
- Applicable Fieldbus protocol: SSCNET III  
(High-speed optical communication, Max. bidirectional communication speed: 50 Mbps)
- Control encoder: Absolute 18-bit encoder (Resolution: 262144 p/rev)

SSCNET III  
SERVO SYSTEM CONTROLLER NETWORK

# AC Servo Motor Driver

## LECS□-T Series

Power supply voltage 200 to 240 VAC  
(LECS-C-T Series: 200 to 230 VAC)

Motor capacity 100/200/400 W

Absolute Type

### LECSB-T Series (Pulse input type/Positioning type)



- Positioning by up to 255 point tables
- Input type: Pulse input (Sink (NPN) type interface/Source (PNP) type interface)
- Control encoder: Absolute 22-bit encoder (Resolution: 4194304 p/rev)
- STO (Safe Torque Off) safety function available
- Parallel input: 10 inputs  
output: 6 outputs

### LECS-C-T Series (CC-Link direct input type)



# CC-Link

- Position data/speed data setting and operation start/stop
- Positioning by up to 255 point tables (when 2 stations are occupied)
- Up to 32 drivers can be connected (when 2 stations are occupied) with CC-Link communication.
- Applicable Fieldbus protocol: CC-Link (Ver. 1.10, Max. communication speed: 10 Mbps)
- Control encoder: Absolute 18-bit encoder (Resolution: 262144 p/rev)

### LECSN-T Series (Network card type)



- Supports **PROFINET**<sup>®</sup>, **EtherCAT**<sup>®</sup>, and **EtherNet/IP**<sup>™</sup>
- Supports 3 types of network card (PROFINET, EtherCAT, and EtherNet/IP<sup>™</sup>)
- STO (Safe Torque Off) safety function available
- Control encoder: Absolute 22-bit encoder (Resolution: 4194304 p/rev)

### LECSS-T Series (SSCNET III/H type)



# SSCNET III/H

SERVO SYSTEM CONTROLLER NETWORK

- Applicable Fieldbus protocol: **SSCNET III/H**  
(High-speed optical communication, max. bidirectional communication speed: 150 Mbps)
- Bidirectional communication speed: 3 times
- SSCNET III/H and SSCNET III products are compatible.
- Improved noise resistance
- STO (Safe Torque Off) safety function available
- Control encoder: Absolute 22-bit encoder (Resolution: 4194304 p/rev)

# AC Servo Motor Driver

LECY□ Series

Power supply voltage 200 to 230 VAC


Motor capacity 100/200/400 W

Absolute Type

## LECYM Series (MECHATROLINK-II type)




 MECHATROLINK-II

- **Applicable Fieldbus protocol:**  MECHATROLINK-II
- **Number of connectable drivers:** 30 units (Transmission distance: Max. 50 m in total)
- **Max. transmission speed:** 10 Mbps
- **Min. transmission cycle:** 250  $\mu$ s
- **Control encoder:** Absolute 20-bit encoder (Resolution: 1048576 p/rev)
- **STO (Safe Torque Off) safety function available**
- **Compliant with the SEMI F47 Standard (Torque limit for low DC power supply voltage for main circuit)**

## LECYU Series (MECHATROLINK-III type)



 MECHATROLINK-III

- **Applicable Fieldbus protocol:**  MECHATROLINK-III
- **Number of connectable drivers:** 62 units (Transmission distance: Max. 75 m between stations)
- **Max. transmission speed:** 100 Mbps
- **Min. transmission cycle:** 125  $\mu$ s
- **Control encoder:** Absolute 20-bit encoder (Resolution: 1048576 p/rev)
- **STO (Safe Torque Off) safety function available**
- **Compliant with the SEMI F47 Standard (Torque limit for low DC power supply voltage for main circuit)**

# CONTENTS

## AC Servo Motor

### Incremental Type/Absolute Type LECS□/LECS□-T Series



How to Order .....	p. 13
Dimensions .....	p. 14
Specifications .....	p. 17
Power Supply Wiring Example .....	p. 21
Control Signal Wiring Example .....	p. 25
Options .....	p. 34

## AC Servo Motor

### MECHATROLINK Compatible Absolute Type LECY□ Series



How to Order .....	p. 39
Dimensions .....	p. 39
Specifications .....	p. 40
Power Supply Wiring Example .....	p. 42
Control Signal Wiring Example .....	p. 43
Options .....	p. 45

Specific Product Precautions .....	p. 49
------------------------------------	-------

# AC Servo Motor Driver Incremental Type

**LECSA Series** (Pulse Input Type/Positioning Type)



\* Only the LECSA and LECSA-T are compliant. The LECSN-T is only compliant if the "Without network card" option is selected.

# Absolute Type

**LECSB** (Pulse Input Type)/**LECSA** (CC-Link Direct Input Type)/**LECSA** (SSCNET III Type)

**LECSB-T** (Pulse Input Type/Positioning Type)/**LECSA-T** (CC-Link Direct Input Type)

**LECSN-T** (Network Card Type)/**LECSA-T** (SSCNET III/H Type) **Series**

Compatible actuators

LEF LEJ LEY

## How to Order

### For LECSA/LECSB/LECSA/LECSA

**LECS A 1 - S1**

Driver type

A	Pulse input type/Positioning type (For incremental encoder)
B	Pulse input type (For absolute encoder)
C	CC-Link direct input type (For absolute encoder)
S	SSCNET III type (For absolute encoder)

Power supply voltage

1	100 to 120 VAC, 50/60 Hz
2	200 to 230 VAC, 50/60 Hz



LECSA LECSB LECSA LECSA

- \* If an I/O connector is required, order the part number "LE-CSN□" separately.
- \* If an I/O cable is required, order the part number "LEC-CSN□-1" separately.  
(Since the electric actuator will not operate without emergency stop (EMG) wiring for the LECSB, an I/O connector or an I/O cable is required.)

Compatible motor type

Symbol	Type	Capacity	Encoder
S1	AC servo motor (S2*1)	100 W	Incremental
S3	AC servo motor (S3*1)	200 W	
S4	AC servo motor (S4*1)*2	400 W	
S5	AC servo motor (S6*1)	100 W	Absolute
S7	AC servo motor (S7*1)	200 W	
S8	AC servo motor (S8*1)*2	400 W	

\*1 The symbol shows the motor type (actuator).

\*2 Only available for power supply voltage "200 to 230 VAC"

### For LECSB-T/LECSA-T/LECSA-T

**LECS B 2 - T5**

Driver type

B	Pulse input type/Positioning type (For absolute encoder)
C	CC-Link direct input type (For absolute encoder)
S	SSCNET III/H type (For absolute encoder)

Power supply voltage

2	200 to 240 VAC, 50/60 Hz (For LECSB2-T/LECSA2-T) 200 to 230 VAC, 50/60 Hz (For LECSA2-T)
---	---



LECSB-T LECSA-T LECSA-T

- \* If an I/O connector is required, order the part number "LE-CSN□" separately.
- \* If an I/O cable is required, order the part number "LEC-CSN□-1" separately.  
(Since the electric actuator will not operate without forced stop (EM2) wiring when using the LECSB-T in any mode other than positioning mode, an I/O connector or an I/O cable is required.)

Compatible motor type

Symbol	Type	Capacity	Encoder
T5	AC servo motor (T6*1)	100 W	Absolute
T7	AC servo motor (T7*1)	200 W	
T8	AC servo motor (T8*1)	400 W	
T9	AC servo motor (T9*1, *2)	750 W	

\*1 The symbol shows the motor type (actuator).

\*2 Only supports the pulse input type/positioning type driver type

### For LECSN-T

**LECS N 2 - T5 - 9**

Driver type

N	Network card type (For absolute encoder)
---	---

Power supply voltage

2	200 to 240 VAC, 50/60 Hz
---	--------------------------

Compatible motor type

Symbol	Type	Capacity	Encoder
T5	AC servo motor (T6*1)	100 W	Absolute
T7	AC servo motor (T7*1)	200 W	
T8	AC servo motor (T8*1)	400 W	
T9	AC servo motor (T9*1)	750 W	

\*1 The symbol shows the motor type (actuator).



LECSN-T

- \* If an I/O connector is required, order the part number "LE-CSNS" separately.
- \* If an I/O cable is required, order the part number "LEC-CSNS-1" separately.


Network card type\*1

—	Without network card
E	EtherCAT
9	EtherNet/IP™
P	PROFINET

\*1 Only the "Without network card" option is UL compliant.


## Dimensions

### LECSA□





For LECSA□-S1, S3

For LECSA□-S4





Connector name	Description
<b>CN1</b>	I/O signal connector
<b>CN2</b>	Encoder connector
<b>CN3</b>	USB communication connector
<b>CNP1</b>	Main circuit power supply connector
<b>CNP2</b>	Control circuit power supply connector

### LECSB□





Connector name	Description
<b>CN1</b>	I/O signal connector
<b>CN2</b>	Encoder connector
<b>CN3</b>	RS-422 communication connector
<b>CN4</b>	Battery connector
<b>CN5</b>	USB communication connector
<b>CN6</b>	Analogue monitor connector
<b>CNP1</b>	Main circuit power supply connector
<b>CNP2</b>	Control circuit power supply connector
<b>CNP3</b>	Servo motor power connector

### LECS□



Connector name	Description
<b>CN1</b>	CC-Link connector
<b>CN2</b>	Encoder connector
<b>CN3</b>	RS-422 communication connector
<b>CN4</b>	Battery connector
<b>CN5</b>	USB communication connector
<b>CN6</b>	I/O signal connector
<b>CNP1</b>	Main circuit power supply connector
<b>CNP2</b>	Control circuit power supply connector
<b>CNP3</b>	Servo motor power connector

### LECSS□




Connector name	Description
<b>CN1A</b>	Front axis connector for SSCNET III optical cable
<b>CN1B</b>	Rear axis connector for SSCNET III optical cable
<b>CN2</b>	Encoder connector
<b>CN3</b>	I/O signal connector
<b>CN4</b>	Battery connector
<b>CN5</b>	USB communication connector
<b>CNP1</b>	Main circuit power supply connector
<b>CNP2</b>	Control circuit power supply connector
<b>CNP3</b>	Servo motor power connector

# LECS□/LECS□-T Series

## Dimensions


### LECSB2-T□



Connector name	Description
<b>CN1</b>	I/O signal connector
<b>CN2</b>	Encoder connector
<b>CN3</b>	RS-422 communication connector
<b>CN4</b>	Battery connector
<b>CN5</b>	USB communication connector
<b>CN6</b>	Analogue monitor connector
<b>CN8</b>	STO input signal connector
<b>CNP1</b>	Main circuit power supply connector
<b>CNP2</b>	Control circuit power supply connector
<b>CNP3</b>	Servo motor power connector


Dimensions		[mm]		
Model	W	L	D	M
<b>LECSB2-T5</b>	40	135	4	6
<b>LECSB2-T7</b>				
<b>LECSB2-T8</b>		170	5	
<b>LECSB2-T9</b>	60	185	6	12

### LECS2-T□



Connector name	Description
<b>CN1</b>	CC-Link connector
<b>CN2</b>	Encoder connector
<b>CN3</b>	RS-422 communication connector
<b>CN4</b>	Battery connector
<b>CN5</b>	USB communication connector
<b>CN6</b>	I/O signal connector
<b>CNP1</b>	Main circuit power supply connector
<b>CNP2</b>	Control circuit power supply connector
<b>CNP3</b>	Servo motor power connector

### LECSN2-T□




Connector name	Description
<b>CN3</b>	I/O signal connector
<b>CN2</b>	Encoder connector
<b>CN4</b>	Battery connector
<b>CN5</b>	USB communication connector
<b>CN8</b>	STO input signal connector
<b>CNP1</b>	Main circuit power supply connector
<b>CNP2</b>	Control circuit power supply connector
<b>CNP3</b>	Servo motor power connector
<b>SLOT</b>	Network card slot

Dimensions		[mm]		
Model	W	L	D	M
<b>LECSN2-T5</b>	50	161	5	6
<b>LECSN2-T7</b>				
<b>LECSN2-T8</b>				
<b>LECSN2-T9</b>	60	191	6	12



**Dimensions**

**LECSS2-T□**



Connector name	Description
<b>CN1A</b>	Front axis connector for SSCNET III/H
<b>CN1B</b>	Rear axis connector for SSCNET III/H
<b>CN2</b>	Encoder connector
<b>CN3</b>	I/O signal connector
<b>CN4</b>	Battery connector
<b>CN5</b>	USB communication connector
<b>CN8</b>	STO input signal connector
<b>CNP1</b>	Main circuit power supply connector
<b>CNP2</b>	Control circuit power supply connector
<b>CNP3</b>	Servo motor power connector

**Dimensions** [mm]

Model	W	L	D	M
<b>LECSS2-T5</b>	40	135	4	6
<b>LECSS2-T7</b>		170	5	
<b>LECSS2-T8</b>				

\* Battery included

# LECS□/LECS□-T Series

## Specifications

### LECSA Series

Model		LECSA1-S1	LECSA1-S3	LECSA2-S1	LECSA2-S3	LECSA2-S4
Compatible motor capacity [W]		100	200	100	200	400
Compatible encoder		Incremental 17-bit encoder (Resolution: 131072 p/rev)				
Main power supply	Power voltage [V]	Single phase 100 to 120 VAC (50/60 Hz)		Single phase 200 to 230 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]	Single phase 85 to 132 VAC		Single phase 170 to 253 VAC		
	Rated current [A]	3.0	5.0	1.5	2.4	4.5
Control power supply	Control power supply voltage [V]	24 VDC				
	Allowable voltage fluctuation [V]	21.6 to 26.4 VDC				
	Rated current [A]	0.5				
Parallel input		6 inputs				
Parallel output		4 outputs				
Max. input pulse frequency [pps]		1 M (for differential receiver), 200 k (for open collector)*2				
Function	In-position range setting [pulse]	0 to ±65535 (Command pulse unit)				
	Error excessive	±3 rotations				
	Torque limit	Parameter setting				
	Communication	USB communication				
Point table		Up to 7 points				
Operating temperature range [°C]		0 to 55 (No freezing)				
Operating humidity range [%RH]		90 or less (No condensation)				
Storage temperature range [°C]		-20 to 65 (No freezing)				
Storage humidity range [%RH]		90 or less (No condensation)				
Insulation resistance [MΩ]		Between the housing and SG: 10 (500 VDC)				
Weight [g]		600				700

### LECSB Series

Model		LECSB1-S5	LECSB1-S7	LECSB2-S5	LECSB2-S7	LECSB2-S8
Compatible motor capacity [W]		100	200	100	200	400
Compatible encoder		Absolute 18-bit encoder (Resolution: 262144 p/rev)				
Main power supply	Power voltage [V]	Single phase 100 to 120 VAC (50/60 Hz)		Three phase 200 to 230 VAC (50/60 Hz) Single phase 200 to 230 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]	Single phase 85 to 132 VAC		Three phase 170 to 253 VAC Single phase 170 to 253 VAC		
	Rated current [A]	3.0	5.0	0.9	1.5	2.6
Control power supply	Control power supply voltage [V]	Single phase 100 to 120 VAC (50/60 Hz)		Single phase 200 to 230 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]	Single phase 85 to 132 VAC		Single phase 170 to 253 VAC		
	Rated current [A]	0.4		0.2		
Parallel input		10 inputs				
Parallel output		6 outputs				
Max. input pulse frequency [pps]		1 M (for differential receiver), 200 k (for open collector)*2				
Function	In-position range setting [pulse]	0 to ±10000 (Command pulse unit)				
	Error excessive	±3 rotations				
	Torque limit	Parameter setting or external analogue input setting (0 to 10 VDC)				
	Communication	USB communication, RS422 communication*1				
Operating temperature range [°C]		0 to 55 (No freezing)				
Operating humidity range [%RH]		90 or less (No condensation)				
Storage temperature range [°C]		-20 to 65 (No freezing)				
Storage humidity range [%RH]		90 or less (No condensation)				
Insulation resistance [MΩ]		Between the housing and SG: 10 (500 VDC)				
Weight [g]		800				1000

\*1 USB communication and RS422 communication cannot be performed at the same time.

\*2 If the command pulse input is open collector method, it supports only the sink (NPN) type interface. It does not correspond to the source (PNP) type interface.

## Specifications

### LECS Series

Model		LECS1-S5	LECS1-S7	LECS2-S5	LECS2-S7	LECS2-S8	
<b>Compatible motor capacity [W]</b>		100	200	100	200	400	
<b>Compatible encoder</b>		Absolute 18-bit encoder (Resolution: 262144 p/rev)					
<b>Main power supply</b>	<b>Power voltage [V]</b>	Single phase 100 to 120 VAC (50/60 Hz)		Three phase 200 to 230 VAC (50/60 Hz) Single phase 200 to 230 VAC (50/60 Hz)			
	<b>Allowable voltage fluctuation [V]</b>	Single phase 85 to 132 VAC		Three phase 170 to 253 VAC Single phase 170 to 253 VAC			
	<b>Rated current [A]</b>	3.0	5.0	0.9	1.5	2.6	
<b>Control power supply</b>	<b>Control power supply voltage [V]</b>	Single phase 100 to 120 VAC (50/60 Hz)		Single phase 200 to 230 VAC (50/60 Hz)			
	<b>Allowable voltage fluctuation [V]</b>	Single phase 85 to 132 VAC		Single phase 170 to 253 VAC			
	<b>Rated current [A]</b>	0.4		0.2			
<b>Communication specifications</b>	<b>Applicable Fieldbus protocol (Version)</b>		CC-Link communication (Ver. 1.10)				
	<b>Connection cable</b>		CC-Link Ver. 1.10 compliant cable (Shielded 3-core twisted pair cable)*1				
	<b>Remote station number</b>		1 to 64				
	<b>Cable length</b>	<b>Communication speed [bps]/ Maximum overall cable length [m]</b>	16 k/1200, 625 k/900, 2.5 M/400, 5 M/160, 10 M/100				
		<b>Cable length between stations [m]</b>	0.2 or more				
	<b>I/O occupation area (Inputs/Outputs)</b>		1 station occupied (Remote I/O 32 points/32 points)/(Remote register 4 words/4 words) 2 stations occupied (Remote I/O 64 points/64 points)/(Remote register 8 words/8 words)				
	<b>Number of connectable drivers</b>		Up to 42 (when 1 station is occupied by 1 driver), Up to 32 (when 2 stations are occupied by 1 driver), when there are only remote device stations.				
<b>Command method</b>	<b>Remote register input</b>		Available with CC-Link communication (2 stations occupied)				
	<b>Point table No. input</b>		Available with CC-Link communication, RS422 communication CC-Link communication (1 station occupied): 31 points CC-Link communication (2 stations occupied): 255 points RS422 communication: 255 points				
	<b>Indexer positioning input</b>		Available with CC-Link communication CC-Link communication (1 station occupied): 31 points CC-Link communication (2 stations occupied): 255 points				
<b>Communication function</b>		USB communication, RS-422 communication*2					
<b>Operating temperature range [°C]</b>		0 to 55 (No freezing)					
<b>Operating humidity range [%RH]</b>		90 or less (No condensation)					
<b>Storage temperature range [°C]</b>		-20 to 65 (No freezing)					
<b>Storage humidity range [%RH]</b>		90 or less (No condensation)					
<b>Insulation resistance [MΩ]</b>		Between the housing and SG: 10 (500 VDC)					
<b>Weight [g]</b>		800				1000	

\*1 If the system comprises of both CC-Link Ver. 1.00 and Ver. 1.10 compliant cables, Ver. 1.00 specifications are applied to the overall cable length and the cable length between stations.

\*2 USB communication and RS422 communication cannot be performed at the same time.

### LECS Series

Model		LECS1-S5	LECS1-S7	LECS2-S5	LECS2-S7	LECS2-S8
<b>Compatible motor capacity [W]</b>		100	200	100	200	400
<b>Compatible encoder</b>		Absolute 18-bit encoder (Resolution: 262144 p/rev)				
<b>Main power supply</b>	<b>Power voltage [V]</b>	Single phase 100 to 120 VAC (50/60 Hz)		Three phase 200 to 230 VAC (50/60 Hz) Single phase 200 to 230 VAC (50/60 Hz)		
	<b>Allowable voltage fluctuation [V]</b>	Single phase 85 to 132 VAC		Three phase 170 to 253 VAC Single phase 170 to 253 VAC		
	<b>Rated current [A]</b>	3.0	5.0	0.9	1.5	2.6
<b>Control power supply</b>	<b>Control power supply voltage [V]</b>	Single phase 100 to 120 VAC (50/60 Hz)		Single phase 200 to 230 VAC (50/60 Hz)		
	<b>Allowable voltage fluctuation [V]</b>	Single phase 85 to 132 VAC		Single phase 170 to 253 VAC		
	<b>Rated current [A]</b>	0.4		0.2		
<b>Applicable Fieldbus protocol</b>		SSCNET III (High-speed optical communication)				
<b>Communication function</b>		USB communication				
<b>Operating temperature range [°C]</b>		0 to 55 (No freezing)				
<b>Operating humidity range [%RH]</b>		90 or less (No condensation)				
<b>Storage temperature range [°C]</b>		-20 to 65 (No freezing)				
<b>Storage humidity range [%RH]</b>		90 or less (No condensation)				
<b>Insulation resistance [MΩ]</b>		Between the housing and SG: 10 (500 VDC)				
<b>Weight [g]</b>		800				1000

# LECS□/LECS□-T Series

## Specifications

### LECSB-T Series

Model		LECSB2-T5	LECSB2-T7	LECSB2-T8	LECSB2-T9
Compatible motor capacity [W]		100	200	400	750
Compatible encoder		Absolute 22-bit encoder (Resolution: 4194304 p/rev)			
Main power supply	Power voltage [V]	Three phase 200 to 240 VAC (50/60 Hz), Single phase 200 to 240 VAC (50/60 Hz)			
	Allowable voltage fluctuation [V]	Three phase 170 to 264 VAC (50/60 Hz), Single phase 170 to 264 VAC (50/60 Hz)			
	Rated current [A]	0.9	1.5	2.6	3.8
Control power supply	Control power supply voltage [V]	Single phase 200 to 240 VAC (50/60 Hz)			
	Allowable voltage fluctuation [V]	Single phase 170 to 264 VAC			
	Rated current [A]	0.2			
Parallel input		10 inputs			
Parallel output		6 outputs			
Max. input pulse frequency [pps]		4 M (for differential receiver), 200 k (for open collector)			
Function	In-position range setting [pulse]	0 to ±65535 (Command pulse unit)			
	Error excessive	±3 rotations			
	Torque limit	Parameter setting or external analogue input setting (0 to 10 VDC)			
	Communication	USB communication, RS422 communication*1			
	Point table	Up to 255 points			
Pushing operation		Point table no. input method, Up to 127 points			
Operating temperature range [°C]		0 to 55 (No freezing)			
Operating humidity range [%RH]		90 or less (No condensation)			
Storage temperature range [°C]		-20 to 65 (No freezing)			
Storage humidity range [%RH]		90 or less (No condensation)			
Insulation resistance [MΩ]		Between the housing and SG: 10 (500 VDC)			
Weight [g]		800	1000	1400	

\*1 USB communication and RS422 communication cannot be performed at the same time.

### LECSC-T Series

Model		LECSC2-T5	LECSC2-T7	LECSC2-T8
Compatible motor capacity [W]		100	200	400
Compatible encoder		Absolute 18-bit encoder (Resolution: 262144 p/rev)		
Main power supply	Power voltage [V]	Three phase 200 to 230 VAC (50/60 Hz), Single phase 200 to 230 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]	Three phase 170 to 253 VAC, Single phase 170 to 253 VAC		
	Rated current [A]	0.9	1.5	2.6
Control power supply	Control power supply voltage [V]	Single phase 200 to 230 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]	Single phase 170 to 253 VAC		
	Rated current [A]	0.2		
Communication specifications	Applicable Fieldbus protocol (Version)		CC-Link communication (Ver. 1.10)	
	Connection cable		CC-Link Ver. 1.10 compliant cable (Shielded 3-core twisted pair cable)*1	
	Remote station number		1 to 64	
	Cable length	Communication speed [bps]/ Maximum overall cable length [m]	16 k/1200, 625 k/900, 2.5 M/400, 5 M/160, 10 M/100	
		Cable length between stations [m]	0.2 or more	
	I/O occupation area (Inputs/Outputs)		1 station occupied (Remote I/O 32 points/32 points)/(Remote register 4 words/4 words) 2 stations occupied (Remote I/O 64 points/64 points)/(Remote register 8 words/8 words)	
	Number of connectable drivers		Up to 42 (when 1 station is occupied by 1 driver), Up to 32 (when 2 stations are occupied by 1 driver), when there are only remote device stations.	
Command method	Remote register input		Available with CC-Link communication (2 stations occupied)	
	Point table No. input		Available with CC-Link communication, RS422 communication CC-Link communication (1 station occupied): 31 points, CC-Link communication (2 stations occupied): 255 points RS422 communication: 255 points	
	Indexer positioning input		Available with CC-Link communication CC-Link communication (1 station occupied): 31 points, CC-Link communication (2 stations occupied): 255 points	
Communication function		USB communication, RS-422 communication*2		
Operating temperature range [°C]		0 to 55 (No freezing)		
Operating humidity range [%RH]		90 or less (No condensation)		
Storage temperature range [°C]		-20 to 65 (No freezing)		
Storage humidity range [%RH]		90 or less (No condensation)		
Insulation resistance [MΩ]		Between the housing and SG: 10 (500 VDC)		
Weight [g]		800	1000	

\*1 If the system comprises of both CC-Link Ver. 1.00 and Ver. 1.10 compliant cables, Ver. 1.00 specifications are applied to the overall cable length and the cable length between stations.

\*2 USB communication and RS422 communication cannot be performed at the same time.

## Specifications

### LECSN-T Series

Model		LECSN2-T5	LECSN2-T7	LECSN2-T8	LECSN2-T9
Compatible motor capacity [W]		100	200	400	750
Compatible encoder		Absolute 22-bit encoder (Resolution: 4194304 p/rev)			
Main power supply	Power voltage [V]	Three phase 200 to 240 VAC (50/60 Hz), Single phase 200 to 240 VAC (50/60 Hz)			
	Allowable voltage fluctuation [V]	Three phase 170 to 264 VAC (50/60 Hz), Single phase 170 to 264 VAC (50/60 Hz)			
	Rated current [A]	0.9	1.5	2.6	3.8
Control power supply	Control power supply voltage [V]	Single phase 200 to 240 VAC (50/60 Hz)			
	Allowable voltage fluctuation [V]	Single phase 170 to 264 VAC			
	Rated current [A]	0.2			
Applicable Fieldbus protocol		PROFINET, EtherCAT, EtherNet/IP™			
Function	Communication	USB communication			
	Point table*1	Up to 255 points			
Operating temperature range [°C]		0 to 55 (No freezing)			
Operating humidity range [%RH]		90 or less (No condensation)			
Storage temperature range [°C]		-20 to 65 (No freezing)			
Storage humidity range [%RH]		90 or less (No condensation)			
Insulation resistance [MΩ]		Between the housing and SG: 10 (500 VDC)			
Weight [g]		1000			1400

\*1 Only supports PROFINET and EtherCAT


### LECSS-T Series

Model		LECSS2-T5	LECSS2-T7	LECSS2-T8
Compatible motor capacity [W]		100	200	400
Compatible encoder		Absolute 22-bit encoder (Resolution: 4194304 p/rev)		
Main power supply	Power voltage [V]	Three phase 200 to 240 VAC (50/60 Hz), Single phase 200 to 240 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]	Three phase 170 to 264 VAC (50/60 Hz), Single phase 170 to 264 VAC (50/60 Hz)		
	Rated current [A]	0.9	1.5	2.6
Control power supply	Control power supply voltage [V]	Single phase 200 to 240 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]	Single phase 170 to 264 VAC		
	Rated current [A]	0.2		
Applicable Fieldbus protocol		SSCNET III/H (High-speed optical communication)		
Communication function		USB communication		
Operating temperature range [°C]		0 to 55 (No freezing)		
Operating humidity range [%RH]		90 or less (No condensation)		
Storage temperature range [°C]		-20 to 65 (No freezing)		
Storage humidity range [%RH]		90 or less (No condensation)		
Insulation resistance [MΩ]		Between the housing and SG: 10 (500 VDC)		
Weight [g]		800		1000

# LECSA□/LECSA□-T Series

## Power Supply Wiring Example: LECSA

### LECSA□-□




### Main Circuit Power Supply Connector: CNP1 \* Accessory

Terminal name	Function	Details
	Protective earth (PE)	Should be grounded by connecting the servo motor's earth terminal and the control panel's protective earth (PE)
L1	Main circuit power supply	Connect the main circuit power supply. LECSA1: Single phase 100 to 120 VAC, 50/60 Hz LECSA2: Single phase 200 to 230 VAC, 50/60 Hz
L2		
P	Regeneration option	Terminal to connect regeneration option LECSA□-S1: Not connected at time of shipping LECSA□-S3, S4: Connected at time of shipping * If regeneration option is required for "Model Selection," connect to this terminal.
C		
U	Servo motor power (U)	Connect to motor cable (U, V, W).
V	Servo motor power (V)	
W	Servo motor power (W)	


### Control Circuit Power Supply Connector: CNP2 \* Accessory

Terminal name	Function	Details
24V	Control circuit power supply (24 V)	24 V side of the control circuit power supply (24 VDC) supplied to the driver
0V	Control circuit power supply (0 V)	0 V side of the control circuit power supply (24 VDC) supplied to the driver




## Power Supply Wiring Example: LECSB, LECS□, LECS□-T

**LECSB1-□**  
**LECS□1-□**  
**LECS□1-□**




**LECSB2-□**  
**LECS□2-□**  
**LECS□2-□**

**For single phase 200 VAC**



**For three phase 200 VAC**



\* For single phase 200 to 230 VAC, power supply should be connected to L1 and L2 terminals, with nothing connected to L3.

### Main Circuit Power Supply Connector: CNP1 \* Accessory


Terminal name	Function	Details
L1	Main circuit power supply	Connect the main circuit power supply. LECSB1/LECS□1/LECS□1: Single phase 100 to 120 VAC, 50/60 Hz Connection terminal: L1, L2 LECSB2/LECS□2/LECS□2: Single phase 200 to 230 VAC, 50/60 Hz Connection terminal: L1, L2 Three phase 200 to 230 VAC, 50/60 Hz Connection terminal: L1, L2, L3
L2		
L3		
N		Do not connect.
P1	Connect between P1 and P2. (Connected at time of shipping)	
P2		

### Control Circuit Power Supply Connector: CNP2 \* Accessory

Terminal name	Function	Details
P	Regeneration option	Connect between P and D. (Connected at time of shipping) * If regeneration option is required for "Model Selection," connect to this terminal.
C		
D		
L11	Control circuit power supply	Connect the control circuit power supply. LECSB1/LECS□1/LECS□1: Single phase 100 to 120 VAC, 50/60 Hz Connection terminal: L11, L21 LECSB2/LECS□2/LECS□2: Single phase 200 to 230 VAC, 50/60 Hz Connection terminal: L11, L21
L21		

### Motor Connector: CNP3 \* Accessory


Terminal name	Function	Details
U	Servo motor power (U)	Connect to motor cable (U, V, W).
V	Servo motor power (V)	
W	Servo motor power (W)	




# LECS□/LECS□-T Series

## Power Supply Wiring Example: LECSB2-T□, LECSS2-T□, LECSN2-T□

For single phase 200 VAC



For three phase 200 VAC



\* For single phase 200 to 240 VAC, power supply should be connected to L1 and L3 terminals, with nothing connected to L2. Please note that the wiring locations differ from the LECS□.

### Main Circuit Power Supply Connector: CNP1 \* Accessory


Terminal name	Function	Details
L1	Main circuit power supply	Connect the main circuit power supply. LECSB2-T/LECSS2-T/LECSN2-T: Single phase 200 to 240 VAC, 50/60 Hz Connection terminal: L1, L3 Three phase 200 to 240 VAC, 50/60 Hz Connection terminal: L1, L2, L3
L2		
L3		
N(-)	Do not connect.	
P3	Connect between P3 and P4. (Connected at time of shipping)	
P4		

### Control Circuit Power Supply Connector: CNP2 \* Accessory

Terminal name	Function	Details
P(+)	Regeneration option	Connect between P(+) and D. (Connected at time of shipping) * If regeneration option is required for "Model Selection," connect to this terminal.
C		
D		
L11	Control circuit power supply	Connect the control circuit power supply. LECSB2-T/LECSS2-T/LECSN2-T: Single phase 200 to 240 VAC, 50/60 Hz Connection terminal: L11, L21
L21		

### Motor Connector: CNP3 \* Accessory


Terminal name	Function	Details
U	Servo motor power (U)	Connect to motor cable (U, V, W).
V	Servo motor power (V)	
W	Servo motor power (W)	






## Power Supply Wiring Example: LECS2-T□

**For single phase 200 VAC**



**For three phase 200 VAC**



\* For single phase 200 to 230 VAC, power supply should be connected to L1 and L2 terminals, with nothing connected to L3.

### Main Circuit Power Supply Connector: CNP1 \* Accessory


Terminal name	Function	Details
L1	Main circuit power supply	Connect the main circuit power supply. LECS2-T: Single phase 200 to 230 VAC, 50/60 Hz Connection terminal: L1, L2 Three phase 200 to 230 VAC, 50/60 Hz Connection terminal: L1, L2, L3
L2		
L3		
N	Do not connect.	
P3	Connect between P3 and P4. (Connected at time of shipping)	
P4		

### Control Circuit Power Supply Connector: CNP2 \* Accessory

Terminal name	Function	Details
P(+)	Regeneration option	Connect between P and D. (Connected at time of shipping) * If regeneration option is required for "Model Selection," connect to this terminal.
C		
D		
L11	Control circuit power supply	Connect the control circuit power supply. LECS2-T: Single phase 200 to 230 VAC, 50/60 Hz Connection terminal: L11, L21
L21		

### Motor Connector: CNP3 \* Accessory

Terminal name	Function	Details
U	Servo motor power (U)	Connect to motor cable (U, V, W).
V	Servo motor power (V)	
W	Servo motor power (W)	




# LECS□/LECS□-T Series

## Control Signal Wiring Example: LECSA

### LECSA□-□

This wiring example shows connection with a PLC (FX3U-□□MT/ES) manufactured by Mitsubishi Electric Corporation as when used in position control mode. Refer to the LECSA series Operation Manual and any technical literature or operation manuals for your PLC and positioning unit before connecting to another PLC or positioning unit.

### Position control mode




- \*1 For preventing electric shock, be sure to connect the driver main circuit power supply connector (CNP1)'s protective earth (PE) terminal (marked ⊕) to the control panel's protective earth (PE).
- \*2 For interface use, supply 24 VDC  $\pm 10\%$  200 mA using an external source. 200 mA is the value when all I/O command signals are being used. In addition, reducing the number of inputs/outputs can decrease the current capacity. Refer to the Operation Manual for required current for interface.
- \*3 The failure (ALM) is normally ON. When it is OFF (alarm occurs), stop the PLC signal using the sequence program.
- \*4 Signals of the same name are connected inside the driver.
- \*5 For command pulse input with an open collector method. When a positioning unit loaded with a differential line driver method is used, it is 10 m or less.
- \*6 If the command pulse input is open collector method, it supports only the sink (NPN) type interface. It does not correspond to the source (PNP) type interface.
- \*7 The Z-phase pulse encoder corresponds to the differential line driver method and the open collector method. If the Z-phase pulse encoder is using the open collector method, it supports only the sink (NPN) type interface. It does not correspond to the source (PNP) type interface.

## Control Signal Wiring Example: LECSA

In this wiring example, the device of the CN1-10 pin in the initial status has been changed to the device shown below. For details on the device and changing method, refer to the LECSA series Operation Manual.  
CN1-10: MEND (Travel completion)

### Positioning mode (Point table method) For sink (NPN) I/O interface




- \*1 For preventing electric shock, be sure to connect the driver's protective earth (PE) terminal (marked  $\oplus$ ) to the control panel's protective earth (PE).
- \*2 For interface use, supply 24 VDC  $\pm$  1.0% 200 mA using an external source. 200 mA is the value when all I/O command signals are being used. In addition, reducing the number of inputs/outputs can decrease the current capacity.
- \*3 The failure (ALM) is normally ON.
- \*4 Signals of the same name are connected inside the driver.
- \*5 The wiring example is for the sink (NPN) type interface. Refer to the LECSA series Operation Manual for the source (PNP) type interface. Note that the 23 pin and 25 pin cannot be used for the source type interface.
- \*6 The Z-phase pulse encoder corresponds to the differential line driver method and the open collector method. If the Z-phase pulse encoder is using the open collector method, it supports only the sink (NPN) type interface. It does not correspond to the source (PNP) type interface.

# LECS□/LECS□-T Series


## Control Signal Wiring Example: LECSB

This wiring example shows connection with a positioning unit (QD75D) manufactured by Mitsubishi Electric Corporation as when used in position control mode. Refer to the LECSB series Operation Manual and any technical literature or operation manuals for your PLC and positioning unit before connecting to another PLC or positioning unit.



- \*1 For preventing electric shock, be sure to connect the driver's protective earth (PE) terminal (marked ⊕) to the control panel's protective earth (PE).
- \*2 For interface use, supply 24 VDC  $\pm 10\%$  300 mA using an external source.
- \*3 The failure (ALM) is normally ON. When it is OFF (alarm occurs), stop the PLC signal using the sequence program.
- \*4 Signals of the same name are connected inside the driver.
- \*5 For command pulse input with a differential line driver method. For open collector method, it is 2 m or less.
- \*6 If the command pulse input is open collector method, it supports only the sink (NPN) type interface. It does not correspond to the source (PNP) type interface.
- \*7 The Z-phase pulse encoder corresponds to the differential line driver method and the open collector method. If the Z-phase pulse encoder is using the open collector method, it supports only the sink (NPN) type interface. It does not correspond to the source (PNP) type interface.


**Control Signal Wiring Example: LECS□, LECS□-T□**



\*1 For preventing electric shock, be sure to connect the driver's protective earth (PE) terminal (marked ⊕) to the control panel's protective earth (PE).  
 \*2 For interface use, supply 24 VDC ±10 % 150 mA using an external source.  
 \*3 The failure (ALM) is normally ON. When it is OFF (alarm occurs), stop the PLC signal using the sequence program.

# LECS□/LECS□-T Series

## Control Signal Wiring Example: LECS□



- \*1 For preventing electric shock, be sure to connect the driver's protective earth (PE) terminal (marked ⊕) to the control panel's protective earth (PE).
- \*2 For interface use, supply 24 VDC ±10 % 150 mA using an external source.
- \*3 The failure (ALM) is normally ON. When it is OFF (alarm occurs), stop the PLC signal using the sequence program.
- \*4 Signals of the same name are connected inside the driver.
- \*5 Use the following SSCNET III optical cables. Refer to the "SSCNET III optical cable" on page 35 for cable product numbers.


Cable	Product no.	Cable length
SSCNET III optical cable	LE-CSS-□	0.15 m to 3 m

- \*6 Connections from Axis 2 onward are omitted.
- \*7 Up to 16 axes can be set.
- \*8 Be sure to place a cap on unused CN1A/CN1B.

## Control Signal Wiring Example: LECSB2-T□

This wiring example shows connection with a positioning unit (QD75D) manufactured by Mitsubishi Electric Corporation as when used in position control mode. Refer to the LECSB 2-T series Operation Manual and any technical literature or operation manuals for your PLC and positioning unit before connecting to another PLC or positioning unit.

### Position control mode For sink (NPN) I/O interface




\*1 For preventing electric shock, be sure to connect the driver's protective earth (PE) terminal (marked ⊕) to the control panel's protective earth (PE).  
 \*2 For interface use, supply 24 VDC ±10 % using an external source. Set the total current capacity to 500 mA. 500 mA is the value when all I/O command signals are being used. In addition, reducing the number of inputs/outputs can decrease the current capacity.  
 \*3 The failure (ALM) is normally ON. When it is OFF (alarm occurs), stop the PLC signal using the sequence program.  
 \*4 Signals of the same name are connected inside the driver.  
 \*5 For command pulse input with a differential line driver method. For open collector method, it is 2 m or less.  
 \*6 When not using the STO function, use the driver with the short-circuit connector (provided as an accessory) inserted.  
 \*7 Configure a circuit to turn off EM2 when the main circuit power is turned off to prevent any unexpected restarts of the driver.

# LECS□/LECS□-T Series

## Control Signal Wiring Example: LECSB2-T□

In this wiring example, the devices of the CN1-22 pin, CN1-23 pin, and CN1-25 pin in the initial status have been changed to the devices shown below. For details on the devices and changing method, refer to the LECSB2-T series Operation Manual.  
 CN1-22: CPO (Rough match)/CN1-23: ZP (Return to origin completion)/CN1-25: MEND (Travel completion)


### Positioning mode (Point table method) For sink (NPN) I/O interface



- \*1 For preventing electric shock, be sure to connect the servo amplifier's protective earth (PE) terminal (marked  $\oplus$ ) to the control panel's protective earth (PE).
- \*2 For interface use, supply 24 VDC  $\pm 10\%$  using an external source. Set the total current capacity to 500 mA. 500 mA is the value when all I/O command signals are being used. In addition, reducing the number of inputs/outputs can decrease the current capacity.
- \*3 The ALM (Failure) is normally ON. (Normally closed contact)
- \*4 Signals of the same name are connected inside the servo amplifier.
- \*5 When not using the STO function, use the servo amplifier with the short-circuit connector (provided as an accessory) inserted.
- \*6 Configure a circuit to turn off EM2 when the main circuit power is turned off to prevent any unexpected restarts of the driver.
- \*7 Output devices are not assigned in the initial status. Assign the output devices as necessary.



## Control Signal Wiring Example: LECSN2-T□




- \*1 For preventing electric shock, be sure to connect the driver's protective earth (PE) terminal (marked ⊕) to the control panel's protective earth (PE).
- \*2 If the master equipment does not have forced stop function, always install the forced stop 2 switch (normally closed contact).
- \*3 Configure a circuit to turn off EM2 when the main circuit power is turned off to prevent any unexpected restarts of the driver.
- \*4 When not using the STO function, use the driver with the short-circuit connector (provided as an accessory) inserted.
- \*5 For interface use, supply 24 VDC  $\pm 10\%$  using an external source. Set the total current capacity to 300 mA. 300 mA is the value when all I/O command signals are being used. In addition, reducing the number of inputs/outputs can decrease the current capacity.
- \*6 The ALM (Failure) is normally ON. (Normally closed contact)
- \*7 Signals of the same name are connected inside the driver.

# LECS□/LECS□-T Series

## Control Signal Wiring Example: LECSS2-T□

For sink (NPN) I/O interface





- \*1 For preventing electric shock, be sure to connect the driver's protective earth (PE) terminal (marked ⊕) to the control panel's protective earth (PE).
- \*2 For interface use, supply 24 VDC ±10 % using an external source.
- \*3 The failure (ALM) is normally ON. When it is OFF (alarm occurs), stop the master PLC signal using the master PLC program.
- \*4 Signals of the same name are connected inside the driver.
- \*5 Use the following SSCNET III optical cables. Refer to the "SSCNET III optical cable" on page 35 for cable product numbers.

Cable	Product no.	Cable length
SSCNET III optical cable	LE-CSS-□	0.15 m to 3 m


- \*6 Connections from Axis 2 onward are omitted.
- \*7 Up to 64 axes can be set for the axis selection rotary switch (SW1) and auxiliary axis number setting switches (SW2-3, SW2-4) in combination. Note that the number of connection axes depends on the specifications of the master PLC.
- \*8 Be sure to place a cap on unused CN1A/CN1B.
- \*9 When not using the STO function, use the driver with the short-circuit connector (provided as an accessory) inserted.
- \*10 Configure a circuit to turn off EM2 when the main circuit power is turned off to prevent any unexpected restarts of the driver.

**Options**

Motor cable, Lock cable, Encoder cable (LECS□, LECS□-T common)



**LE-CSM-□□: Motor cable**




Product no.	∅ D
LE-CSM-S□A	6.2
LE-CSM-S□B	6.2
LE-CSM-R□A	5.7
LE-CSM-R□B	5.7

**Weight**

Product no.	Length [m]	Weight [g]
LE-CSM-S2□	2	180
LE-CSM-S5□	5	400
LE-CSM-SA□	10	800
LE-CSM-R2□	2	180
LE-CSM-R5□	5	400
LE-CSM-RA□	10	800

**LE-CSB-□□: Lock cable\*1**




Product no.	∅ D
LE-CSB-S□A	4.7
LE-CSB-S□B	4.7
LE-CSB-R□A	4.5
LE-CSB-R□B	4.5

**Weight**

Product no.	Length [m]	Weight [g]
LE-CSB-S2□	2	80
LE-CSB-S5□	5	200
LE-CSB-SA□	10	400
LE-CSB-R2□	2	80
LE-CSB-R5□	5	200
LE-CSB-RA□	10	400

**LE-CSE-□□: Encoder cable**



\*1 If using an actuator with a lock, a lock cable is required.

**Weight**


Product no.	Length [m]	Weight [g]
LE-CSE-S2□	2	220
LE-CSE-S5□	5	600
LE-CSE-SA□	10	1200
LE-CSE-R2□	2	220
LE-CSE-R5□	5	600
LE-CSE-RA□	10	1200

**I/O connector (Without cable, Connector only)**


**LE - CSN A**

Driver type	
A	LECSA□, LECS□-S□/LECS□-T□
B	LECSB□-S□/LECSB2-T□
S	LECSN2-T□, LECSS□-S□/LECSS2-T□


**LE-CSNA**



**LE-CSNB**



**LE-CSNS**



**Weight**

Product no.	Weight [g]
LE-CSNA	25
LE-CSNB	30
LE-CSNS	16


\* LE-CSNA: 10126-3000PE (connector)/10326-52F0-008 (shell kit) manufactured by 3M Japan Limited or equivalent  
 LE-CSNB: 10150-3000PE (connector)/10350-52F0-008 (shell kit) manufactured by 3M Japan Limited or equivalent  
 LE-CSNS: 10120-3000PE (connector)/10320-52F0-008 (shell kit) manufactured by 3M Japan Limited or equivalent

\* Applicable conductor size: AWG24 to 30  
 \* If using the LECSB, emergency stop (EMG) wiring is required in all cases. If using the LECSB-T in any mode other than positioning mode, forced stop (EM2) wiring is required in all cases. (The electric actuator will not operate without the wiring.)  
 Prepare an I/O connector or an I/O cable in advance.

# LECS□/LECS□-T Series

## Options

SSCNET III optical cable (LECSS□-S□, LECS2-T□)





\* LE-CSS-□ is MR-J3BUS□M manufactured by Mitsubishi Electric Corporation.

### Weight

Product no.	Length [m]	Weight [g]
LE-CSS-L	0.15	100
LE-CSS-K	0.3	100
LE-CSS-J	0.5	200
LE-CSS-1	1	200
LE-CSS-3	3	200

I/O cable



- \* LEC-CSNA-1: 10126-3000PE (connector)/10326-52F0-008 (shell kit) manufactured by 3M Japan Limited or equivalent
- \* LEC-CSNB-1: 10150-3000PE (connector)/10350-52F0-008 (shell kit) manufactured by 3M Japan Limited or equivalent
- \* LEC-CSNS-1: 10120-3000PE (connector)/10320-52F0-008 (shell kit) manufactured by 3M Japan Limited or equivalent
- \* Conductor size: AWG24
- \* If using the LECSB, emergency stop (EMG) wiring is required in all cases. If using the LECSB-T in any mode other than positioning mode, forced stop (EM 2) wiring is required in all cases. (The electric actuator will not operate without the wiring.)
- \* Prepare an I/O connector or an I/O cable in advance.

### Cable O.D.

Product no.	Ø D
LEC-CSNA-1	11.1
LEC-CSNB-1	13.8
LEC-CSNS-1	9.1

### Dimensions/Pin Nos.

Product no.	W	H	T	U	Pin no. n
LEC-CSNA-1	39	37.2	12.7	14	14
LEC-CSNB-1		52.4		18	26
LEC-CSNS-1		33.3		14	21

### Wiring

LEC-CSNA-1: Pin nos. 1 to 26

LEC-CSNB-1: Pin nos. 1 to 50

LEC-CSNS-1: Pin nos. 1 to 20

Connector pin no.	Pair no. of wire	Insulation colour	Dot mark	Dot colour	
A side	1	1	Orange	■	Red
	2	1		■	Black
	3	2	Light grey	■	Red
	4	2		■	Black
	5	3	White	■	Red
	6	3		■	Black
	7	4	Yellow	■	Red
	8	4		■	Black
	9	5	Pink	■	Red
	10	5		■	Black
	11	6	Orange	■ ■	Red
	12	6		■ ■	Black
	13	7	Light grey	■ ■	Red
	14	7		■ ■	Black
	15	8	White	■ ■	Red
	16	8		■ ■	Black
	17	9	Yellow	■ ■	Red
	18	9		■ ■	Black

Connector pin no.	Pair no. of wire	Insulation colour	Dot mark	Dot colour	
A side	19	10	Pink	■ ■	Red
	20	10		■ ■	Black
	21	11	Orange	■ ■ ■ ■	Red
	22	11		■ ■ ■ ■	Black
	23	12	Light grey	■ ■ ■ ■	Red
	24	12		■ ■ ■ ■	Black
	25	13	White	■ ■ ■ ■	Red
	26	13		■ ■ ■ ■	Black
	27	14	Yellow	■ ■ ■ ■	Red
	28	14		■ ■ ■ ■	Black
	29	15	Pink	■ ■ ■ ■	Red
	30	15		■ ■ ■ ■	Black
	31	16	Orange	■ ■ ■ ■ ■ ■	Red
	32	16		■ ■ ■ ■ ■ ■	Black
	33	17	Light grey	■ ■ ■ ■ ■ ■	Red
	34	17		■ ■ ■ ■ ■ ■	Black

Connector pin no.	Pair no. of wire	Insulation colour	Dot mark	Dot colour	
A side	35	18	White	■ ■ ■ ■ ■ ■	Red
	36	18		■ ■ ■ ■ ■ ■	Black
	37	19	Yellow	■ ■ ■ ■ ■ ■	Red
	38	19		■ ■ ■ ■ ■ ■	Black
	39	20	Pink	■ ■ ■ ■ ■ ■	Red
	40	20		■ ■ ■ ■ ■ ■	Black
	41	21	Orange	■ ■ ■ ■ ■ ■ ■ ■	Red
	42	21		■ ■ ■ ■ ■ ■ ■ ■	Black
	43	22	Light grey	■ ■ ■ ■ ■ ■ ■ ■	Red
	44	22		■ ■ ■ ■ ■ ■ ■ ■	Black
	45	23	White	■ ■ ■ ■ ■ ■ ■ ■	Red
	46	23		■ ■ ■ ■ ■ ■ ■ ■	Black
	47	24	Yellow	■ ■ ■ ■ ■ ■ ■ ■	Red
	48	24		■ ■ ■ ■ ■ ■ ■ ■	Black
	49	25	Pink	■ ■ ■ ■ ■ ■ ■ ■	Red
	50	25		■ ■ ■ ■ ■ ■ ■ ■	Black

**Options**

**Regeneration option (LECS□ common)**


**LEC-MR-RB-12**

**Regeneration option type**


<b>032</b>	Allowable regenerative power 30 W
<b>12</b>	Allowable regenerative power 100 W

\* Confirm regeneration option to be used in "Model Selection."

**LEC-MR-RB-032**



**LEC-MR-RB-12**



**Weight**

Product no.	Weight [kg]
<b>LEC-MR-RB-032</b>	0.5

\* MR-RB032 manufactured by Mitsubishi Electric Corporation

**Weight**

Product no.	Weight [kg]
<b>LEC-MR-RB-12</b>	1.1

\* MR-RB12 manufactured by Mitsubishi Electric Corporation



**Network card (LECSN2-T□)**

**LEC-S-N9**

**Network card type**

<b>N9</b>	EtherNet/IP™
<b>NE</b>	EtherCAT
<b>NP</b>	PROFINET

**LEC-S□ common**



**Weight**

Product no.	Weight [g]
<b>LEC-S□</b>	30

# LECS□/LECS□-T Series

## Options



Setup software (MR Configurator2™) (LECSA, LECSB, LECS, LECS, LECSB2-T, LECS2-T, LECS2-T, LECSN2-T common)

### LEC-MRC2□

#### Display language

—	Japanese version
E	English version
C	Chinese version

\* SW1DNC-MRC2□ manufactured by Mitsubishi Electric Corporation  
Refer to Mitsubishi Electric Corporation's website for operating environment and version upgrade information.  
MR Configurator2™ is a registered trademark or trademark of Mitsubishi Electric Corporation.

Adjustment, waveform display, diagnostics, parameter read/write, and test operation can be performed upon a PC.

### Compatible PC

When using setup software (MR Configurator2™), use an IBM PC/AT compatible PC that meets the following operating conditions.

### Hardware Requirements

Equipment		Setup software (MR Configurator2™) LEC-MRC2□	
*1, 2, 3, 4, 5, 6, 7, 8, 9, 10 PC	OS	Microsoft® Windows® 10 Edition Microsoft® Windows® 10 Enterprise Microsoft® Windows® 10 Pro Microsoft® Windows® 10 Home Microsoft® Windows® 8.1 Enterprise Microsoft® Windows® 8.1 Pro Microsoft® Windows® 8.1 Microsoft® Windows® 8 Enterprise Microsoft® Windows® 8 Pro Microsoft® Windows® 8 Microsoft® Windows® 7 Ultimate Microsoft® Windows® 7 Enterprise Microsoft® Windows® 7 Professional Microsoft® Windows® 7 Home Premium Microsoft® Windows® 7 Starter Microsoft® Windows Vista® Ultimate Microsoft® Windows Vista® Enterprise Microsoft® Windows Vista® Business Microsoft® Windows Vista® Home Premium Microsoft® Windows Vista® Home Basic Microsoft® Windows® XP Professional, Service Pack 3 or later Microsoft® Windows® XP Home Edition, Service Pack 3 or later	*1 Before using a PC for setting LECSA point table method/program operation method, upgrade to version 1.18U (Japanese version)/version 1.19V (English version) or later. Refer to Mitsubishi Electric Corporation's website for version upgrade information. *2 Windows® and Windows Vista® are registered trademarks of Microsoft Corporation in the United States and other countries. *3 On some PCs, setup software (MR Configurator2™) may not run properly. *4 The following functions cannot be used. If any of the following functions is used, this product may not operate normally. · Start of application in Windows® compatible mode · Fast User Switching · Remote Desktop · Windows XP Mode · Windows Touch or Touch · Modern UI · Client Hyper-V · Tablet Mode · Virtual desktop · 64-bit OSs are not supported, except for Microsoft® Windows®7 or later.
	Hard disk	1 GB or more of free space	*5 Multi-display is set, the screen of this product may not operate normally.
	Communication interface	Use USB port.	*6 The size of the text or other items on the screen is not changed to the specified value (96 DPI, 100 %, 9 pt, etc.), the screen of this product may not operate normally.
Display	Resolution 1024 x 768 or more Must be capable of high colour (16-bit) display. Connectable with the PC above		*7 Changed the resolution of the screen during operating, the screen of this product may not operate normally. *8 Please use by "Standard User," "Administrator" in Windows Vista® or later.
Keyboard	Connectable with the PC above		
Mouse	Connectable with the PC above		
Printer	Connectable with the PC above		
USB cable*11	LEC-MR-J3USB		*9 Using a PC for setting Windows®10, upgrade to version 1.52E or later. Using a PC for setting Windows®8.1, upgrade to version 1.25B or later. Using a PC for setting Windows®8, upgrade to version 1.20W or later. Refer to Mitsubishi Electric Corporation's website for version upgrade information.

### Setup Software Compatible Drivers

Compatible driver	Setup software	
	MR Configurator™ LEC-MR-SETUP221□	MR Configurator2™ LEC-MRC2□
LECSA	○	○
LECSB□-S□	○	○
LECS□-S□	○	○
LECS□-S□	○	○
LECSB2-T□	—	○
LECS2-T□	—	○
LECS2-T□	—	○
LECSN2-T□	—	○

\*10 If .NET Framework 3.5 (including .NET 2.0 and 3.0) have been disabled in Windows®7 or later, it is necessary to enable it.  
\*11 Order USB cable separately.  
· This cable is compatible with the setup software (MR Configurator™: LEC-MR-SETUP221□).

## Options

### USB cable (3 m)

(LECSA, LECSB, LECSB, LECSB, LECSB-T, LECSB-T, LECSN-T, LECSN-T, LECSN-T common)

#### LEC-MR-J3USB

\* MR-J3USBCBL3M manufactured by Mitsubishi Electric Corporation

Weight: 140 g

Cable for connecting PC and driver when using the setup software (MR Configurator2™)

Do not use any cable other than this cable.

### STO cable (3 m)


(Only for LECSB2-T□, LECSN2-T□, and LECS2-T□)

#### LEC-MR-D05UDL3M

\* MR-D05UDL3M manufactured by Mitsubishi Electric Corporation

Cable for connecting the driver and device, when using the safety function

Do not use any cable other than this cable.



Weight: 500 g


### Battery

#### LEC-MR-J3BAT

\* MR-J3BAT manufactured by Mitsubishi Electric Corporation

Battery for replacement

Absolute position data is maintained by installing the battery to the driver.



Weight: 30 g


\* The LEC-MR-J3BAT is a single battery that uses lithium metal battery ER6V. When transporting lithium metal batteries and devices with built-in lithium metal batteries by a method subject to UN regulations, it is necessary to apply measures according to the regulations stipulated in the United Nations Recommendations on the Transport of Dangerous Goods, the Technical Instructions (ICAO-TI) of the International Civil Aviation Organisation (ICAO), and the International Maritime Dangerous Goods Code (IMDG CODE) of the International Maritime Organisation (IMO). If a customer is transporting products such as shown above, it is necessary to confirm the latest regulations, or the laws and regulations of the country of transport on your own, in order to apply the proper measures. Please contact SMC sales representative for details.

#### LEC-MR-BAT6V1SET

\* MR-BAT6V1SET manufactured by Mitsubishi Electric Corporation

Battery for replacement

Absolute position data is maintained by installing the battery to the driver.




Weight: 60 g

#### LEC-MR-BAT6V1SET-A

\* MR-BAT6V1SET-A manufactured by Mitsubishi Electric Corporation

Battery for replacement

Absolute position data is maintained by installing the battery to the driver.



Weight: 60 g

\* The LEC-MR-BAT6V1SET and LEC-MR-BAT6V1SET-A are assembled batteries that use lithium metal battery 2CR17335A. When transporting lithium metal batteries and devices with built-in lithium metal batteries by a method subject to UN regulations, it is necessary to apply measures according to the regulations stipulated in the United Nations Recommendations on the Transport of Dangerous Goods, the Technical Instructions (ICAO-TI) of the International Civil Aviation Organisation (ICAO), and the International Maritime Dangerous Goods Code (IMDG CODE) of the International Maritime Organisation (IMO). If a customer is transporting products such as shown above, it is necessary to confirm the latest regulations, or the laws and regulations of the country of transport on your own, in order to apply the proper measures. Please contact SMC sales representative for details.

### Battery Types and Compatible Drivers

Compatible driver	Battery type		
	LEC-MR-J3BAT	LEC-MR-BAT6V1SET	LEC-MR-BAT6V1SET-A
LECSB□-S□	○	—	—
LECSB□-S□	○	—	—
LECSB□-S□	○	—	—
LECSB□-T□	—	○	—
LECSB□-T□	○	—	—
LECSB□-T□	—	○	—
LECSB□-T□	—	—	○

# AC Servo Motor Driver Absolute Type

## LECYM/LECYU Series

(MECHATROLINK-II Type) (MECHATROLINK-III Type)



### How to Order

Driver

LECYM 2 -

Driver type

M	MECHATROLINK-II type (For absolute encoder)
U	MECHATROLINK-III type (For absolute encoder)

Power supply voltage

2	200 to 230 VAC, 50/60 Hz
---	--------------------------

- \* If an I/O connector (CN1) is required, order the part number "LE-CYNA" separately.
- \* If an I/O cable (CN1) is required, order the part number "LEC-CSNA-1" separately.

Compatible motor type


Symbol	Type	Capacity	Encoder
V5	AC servo motor (V6*1)	100 W	Absolute
V7	AC servo motor (V7*1)	200 W	
V8	AC servo motor (V8*1)	400 W	

\*1 The symbol shows the motor type (actuator).

### Dimensions

MECHATROLINK-II type

LECYM2-V



Connector name	Description
CN1	I/O signal connector
CN2	Encoder connector
CN3*1	Digital operator connector
CN6A	MECHATROLINK-II communication connector
CN6B	MECHATROLINK-II communication connector
CN7	PC connector
CN8	Safety connector


\*1 Digital operator is JUSP-OP05A-1-E manufactured by YASKAWA Electric Corporation. When using the digital operator, it should be provided by the customer.

Motor capacity	Hole position	Mounting dimensions				Mounting hole
		A	B	C	D	
V5 (100 W)	①②	5	—	5	5	Ø 5
V7 (200 W)	①②	5	—	5	5	
V8 (400 W)	②③	5	5	5	5	

\* The mounting hole position varies depending on the motor capacity.

MECHATROLINK-III type

LECYU2-V



Connector name	Description
CN1	I/O signal connector
CN2	Encoder connector
CN3*1	Digital operator connector
CN6A	MECHATROLINK-III communication connector
CN6B	MECHATROLINK-III communication connector
CN7	PC connector
CN8	Safety connector

\*1 Digital operator is JUSP-OP05A-1-E manufactured by YASKAWA Electric Corporation. When using the digital operator, it should be provided by the customer.

Motor capacity	Hole position	Mounting dimensions				Mounting hole
		A	B	C	D	
V5 (100 W)	①②	5	—	5	5	Ø 5
V7 (200 W)	①②	5	—	5	5	
V8 (400 W)	②③	5	5	5	5	

\* The mounting hole position varies depending on the motor capacity.



## Specifications

### MECHATROLINK-II Type

Model		LECYM2-V5	LECYM2-V7	LECYM2-V8
Compatible motor capacity [W]		100	200	400
Compatible encoder		Absolute 20-bit encoder (Resolution: 1048576 p/rev)		
Main circuit power supply	Power voltage [V]	Three phase 200 to 230 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]	Three phase 170 to 253 VAC		
Control power supply	Power voltage [V]	Single phase 200 to 230 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]	Single phase 170 to 253 VAC		
Power supply capacity (at rated output) [A]		0.91	1.6	2.8
Input circuit		NPN (Sink circuit)/PNP (Source circuit)		
Parallel input (7 inputs)	Number of optional allocations	7 inputs	[Initial allocation] · Homing deceleration switch (/DEC) · External latch (/EXT 1 to 3) · Forward run prohibited (P-OT), reverse run prohibited (N-OT) [Can be allocated by setting the parameters] · Forward external torque limit (/P-CL), reverse external torque limit (/N-CL) Signal allocations can be performed, and positive and negative logic can be changed.	
Parallel output (4 outputs)	Number of fixed allocations	1 output	· Servo alarm (ALM)	
	Number of optional allocations	3 outputs	[Initial allocation] · Lock (/BK) [Can be allocated by setting the parameters] · Positioning completion (/COIN) · Speed limit detection (/VLT) · Speed coincidence detection (/V-CMP) · Rotation detection (/TGON) · Warning (/WARN) · Servo ready (/S-RDY) · Near (/NEAR) · Torque limit detection (/CLT) Signal allocations can be performed, and positive and negative logic can be changed.	
MECHATROLINK communication	Communication protocol	MECHATROLINK-II		
	Station address	41H to 5FH		
	Transmission speed	10 Mbps		
	Transmission cycle	250 μs, 0.5 ms to 4 ms (Multiples of 0.5 ms)		
	Number of transmission bytes	17 bytes, 32 bytes		
	Max. number of stations	30		
	Cable length	Overall cable length: 50 m or less, Cable length between the stations: 0.5 m or more		
Command method	Control method	Position, speed, or torque control with MECHATROLINK-II communication		
	Command input	MECHATROLINK-II command (Motion, data setting, monitoring, or adjustment)		
Function	Gain adjustment	Tuning-less/Advanced auto tuning/One-parameter tuning		
	Communication setting	USB communication, RS-422 communication		
	Torque limit	Internal torque limit, external torque limit, and torque limit by analogue command		
	Encoder output	Phase A, B, Z: Line driver output		
	Emergency stop	CN8 Safety function		
	Overtravel	Dynamic brake stop, deceleration to a stop, or free run to a stop at P-OT or N-OT		
Alarm	Alarm signal, MECHATROLINK-II command			
Operating temperature range [°C]		0 to 55 (No freezing)		
Operating humidity range [%RH]		90 or less (No condensation)		
Storage temperature range [°C]		-20 to 85 (No freezing)		
Storage humidity range [%RH]		90 or less (No condensation)		
Insulation resistance [MΩ]		10 MΩ (500 VDC)		
Weight [g]		900		1000


## Specifications

### MECHATROLINK-III Type

Model			LECYU2-V5	LECYU2-V7	LECYU2-V8
Compatible motor capacity [W]			100	200	400
Compatible encoder			Absolute 20-bit encoder (Resolution: 1048576 p/rev)		
Main circuit power supply	Power voltage [V]		Three phase 200 to 230 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]		Three phase 170 to 253 VAC		
Control power supply	Power voltage [V]		Single phase 200 to 230 VAC (50/60 Hz)		
	Allowable voltage fluctuation [V]		Single phase 170 to 253 VAC		
Power supply capacity (at rated output) [A]			0.91	1.6	2.8
Input circuit			NPN (Sink circuit)/PNP (Source circuit)		
Parallel input (7 inputs)	Number of optional allocations	7 inputs	[Initial allocation] · Homing deceleration switch (/DEC) · External latch (/EXT 1 to 3) · Forward run prohibited (P-OT), reverse run prohibited (N-OT) [Can be allocated by setting the parameters] · Forward external torque limit (/P-CL), reverse external torque limit (/N-CL) Signal allocations can be performed, and positive and negative logic can be changed.		
			Number of fixed allocations	1 output	· Servo alarm (ALM)
Parallel output (4 outputs)	Number of optional allocations	3 outputs	[Initial allocation] · Lock (/BK) [Can be allocated by setting the parameters] · Positioning completion (/COIN) · Speed limit detection (/VLT) · Speed coincidence detection (/V-CMP) · Rotation detection (/TGON) · Warning (/WARN) · Servo ready (/S-RDY) · Near (/NEAR) · Torque limit detection (/CLT) Signal allocations can be performed, and positive and negative logic can be changed.		
MECHATROLINK communication	Communication protocol		MECHATROLINK-III		
	Station address		03H to EFH		
	Transmission speed		100 Mbps		
	Transmission cycle		125 μs, 250 μs, 500 μs, 750 μs, 1 ms to 4 ms (Multiples of 0.5 ms)		
	Number of transmission bytes		16 bytes, 32 bytes, 48 bytes		
	Max. number of stations		62		
	Cable length		Cable length between the stations: 0.5 m or more, 75 m or less		
Command method	Control method		Position, speed, or torque control with MECHATROLINK-III communication		
	Command input		MECHATROLINK-III command (Motion, data setting, monitoring, or adjustment)		
Function	Gain adjustment		Tuning-less/Advanced auto tuning/One-parameter tuning		
	Communication setting		USB communication, RS-422 communication		
	Torque limit		Internal torque limit, external torque limit, and torque limit by analogue command		
	Encoder output		Phase A, B, Z: Line driver output		
	Emergency stop		CN8 Safety function		
	Overtravel		Dynamic brake stop, deceleration to a stop, or free run to a stop at P-OT or N-OT		
Alarm		Alarm signal, MECHATROLINK-III command			
Operating temperature range [°C]			0 to 55 (No freezing)		
Operating humidity range [%RH]			90 or less (No condensation)		
Storage temperature range [°C]			-20 to 85 (No freezing)		
Storage humidity range [%RH]			90 or less (No condensation)		
Insulation resistance [MΩ]			10 MΩ (500 VDC)		
Weight [g]			900		1000

## Power Supply Wiring Example: LECY□

■ Three phase 200 V **LECYM2-□**  
**LECYU2-□**



\*1 For the LECY□2-V5, LECY□2-V7, and LECY□2-V8, terminals B2 and B3 are not short-circuited. Do not short-circuit these terminals.

### Main Circuit Power Supply Connector \* Accessory

Terminal name	Function	Details
L1	Main circuit power supply	Connect the main circuit power supply. Single phase 200 to 230 VAC, 50/60 Hz Connection terminal: L1, L2 Three phase 200 to 230 VAC, 50/60 Hz Connection terminal: L1, L2, L3
L2		
L3		
L1C	Control power supply	Connect the control power supply. Single phase 200 to 230 VAC, 50/60 Hz Connection terminal: L1C, L2C
L2C		
B1/⊕	External regenerative resistor connection terminal	When the regenerative resistor is required, connect it between terminals B1/⊕ and B2.
B2		
⊖1	Main circuit negative terminal	⊖1 and ⊖2 are connected at shipment.
⊖2		


### Motor Connector \* Accessory

Terminal name	Function	Details
U	Servo motor power (U)	Connect to motor cable (U, V, W).
V	Servo motor power (V)	
W	Servo motor power (W)	

### Power Supply Wire Specifications


Item	Specifications
Applicable wire size	L1, L2, L3, L1C, L2C Single wire, Twisted wire, AWG14 (2.0 mm <sup>2</sup> )
Stripped wire length	8 to 9 mm

### Main circuit power supply connector




## Control Signal Wiring Example: LECYM

Photo-coupler output  
 Max. operating voltage: 30 VDC  
 Max. output current: 50 mA DC



## Control Signal Wiring Example: LECYU



\*1  $\overline{\text{---}}$  shows twisted-pair wires.

\*2 The 24 VDC power supply is not included. Use a 24 VDC power supply with double insulation or reinforced insulation.

\*3 When using the safety function, a safety function device must be connected to the wiring that is necessary to activate the safety function. Otherwise, the servo motor is not turned ON. When not using the safety function, use the driver with the Safety Jumper Connector (provided as an accessory) inserted into the CN8.

\*4 Always use line receivers to receive the output signals.

\*\* The functions allocated to the input signals /DEC, P-OT, N-OT, /EXT 1, /EXT 2, and /EXT 3, and the output signals /SO 1, /SO 2, and /SO 3 can be changed by setting the parameters.

\*5 It is a safety function equivalent to the STO function (IEC 61800-5-2) using the hard wire base block function (HWBB).

## Options

Motor cable, Motor cable for lock option, Encoder cable (LECYM/LECYU common)

**LE-CYM-□□A-□**

● **Motor type**

<b>Y</b>	AC servo motor
----------	----------------

● **Cable description**

<b>M</b>	Motor cable
<b>B</b>	Motor cable for lock option
<b>E</b>	Encoder cable (With battery case)

● **Cable type**

<b>S</b>	Standard cable
<b>R</b>	Robotic cable

● **Cable length (L) [m]**


<b>3</b>	3
<b>5</b>	5
<b>A</b>	10
<b>C</b>	20

● **Motor capacity**

<b>5</b>	100 W
<b>7</b>	200/400 W

\* For encoder cable, the suffix "□□" (Motor capacity) is not necessary.

● **Direction of connector**




\* The cable entry direction is axis side only.

**Weight**


Product no.	Length [m]	Weight [g]	Note
<b>LE-CYM-S3A-5</b>	3	250	100 W
<b>LE-CYM-S5A-5</b>	5	390	
<b>LE-CYM-SAA-5</b>	10	750	
<b>LE-CYM-SCA-5</b>	20	1500	
<b>LE-CYM-S3A-7</b>	3	250	200/ 400 W
<b>LE-CYM-S5A-7</b>	5	390	
<b>LE-CYM-SAA-7</b>	10	750	
<b>LE-CYM-SCA-7</b>	20	1500	
<b>LE-CYM-R3A-5</b>	3	220	100 W
<b>LE-CYM-R5A-5</b>	5	350	
<b>LE-CYM-RAA-5</b>	10	670	
<b>LE-CYM-RCA-5</b>	20	1300	
<b>LE-CYM-R3A-7</b>	3	220	200/ 400 W
<b>LE-CYM-R5A-7</b>	5	350	
<b>LE-CYM-RAA-7</b>	10	670	
<b>LE-CYM-RCA-7</b>	20	1300	

**LE-CYM-□□A-□: Motor cable**




M4 Crimped terminal

**LE-CYB-□□A-□: Motor cable for lock option**



3-M4 Crimped terminal

**LE-CYE-□□A: Encoder cable**



Product no.	∅ D
<b>LE-CYE-S□A</b>	6.5
<b>LE-CYE-R□A</b>	6.8

Battery case  
Depth dimension: 25 mm

**Weight**

Product no.	Length [m]	Weight [g]	Note
<b>LE-CYB-S3A-5</b>	3	240	100 W
<b>LE-CYB-S5A-5</b>	5	390	
<b>LE-CYB-SAA-5</b>	10	750	
<b>LE-CYB-SCA-5</b>	20	1490	
<b>LE-CYB-S3A-7</b>	3	240	200/ 400 W
<b>LE-CYB-S5A-7</b>	5	390	
<b>LE-CYB-SAA-7</b>	10	750	
<b>LE-CYB-SCA-7</b>	20	1490	
<b>LE-CYB-R3A-5</b>	3	220	100 W
<b>LE-CYB-R5A-5</b>	5	350	
<b>LE-CYB-RAA-5</b>	10	670	
<b>LE-CYB-RCA-5</b>	20	1300	
<b>LE-CYB-R3A-7</b>	3	220	200/ 400 W
<b>LE-CYB-R5A-7</b>	5	350	
<b>LE-CYB-RAA-7</b>	10	670	
<b>LE-CYB-RCA-7</b>	20	1300	

**Weight**


Product no.	Length [m]	Weight [g]
<b>LE-CYE-S3A</b>	3	230
<b>LE-CYE-S5A</b>	5	360
<b>LE-CYE-SAA</b>	10	680
<b>LE-CYE-SCA</b>	20	1250
<b>LE-CYE-R3A</b>	3	220
<b>LE-CYE-R5A</b>	5	330
<b>LE-CYE-RAA</b>	10	660
<b>LE-CYE-RCA</b>	20	1240

\* LE-CYM-S□A-□ is JZSP-CSM0□□□□-E manufactured by YASKAWA CONTROLS CO., LTD.  
LE-CYB-S□A-□ is JZSP-CSM1□□□□-E manufactured by YASKAWA CONTROLS CO., LTD.  
LE-CYE-S□A is JZSP-CSP05□□□-E manufactured by YASKAWA CONTROLS CO., LTD.

LE-CYM-R□A-□ is JZSP-CSM2□□□□-E manufactured by YASKAWA CONTROLS CO., LTD.  
LE-CYB-R□A-□ is JZSP-CSM3□□□□-E manufactured by YASKAWA CONTROLS CO., LTD.  
LE-CYE-R□A is JZSP-CSP25□□□-E manufactured by YASKAWA CONTROLS CO., LTD.

**Options**

**I/O connector (Without cable, Connector only)**




**Weight**

Product no.	Weight [g]
<b>LE-CYNA</b>	25


\* LE-CYNA: 10126-3000PE (connector)/10326-52F0-008 (shell kit) manufactured by 3M Japan Limited or equivalent  
 \* Conductor size: AWG24 to 30

**I/O cable**



**Weight**

Product no.	Weight [g]
<b>LEC-CSNA-1</b>	303



\* LEC-CSNA-1: 10126-3000PE (connector)/10326-52F0-008 (shell kit) manufactured by 3M Japan Limited or equivalent  
 \* Conductor size: AWG24

**Wiring**

LEC-CSNA-1: Pin nos. 1 to 26

Connector pin no.	Pair no. of wire	Insulation colour	Dot mark	Dot colour	Connector pin no.	Pair no. of wire	Insulation colour	Dot mark	Dot colour	Connector pin no.	Pair no. of wire	Insulation colour	Dot mark	Dot colour			
<b>A side</b>	1	1	Orange	■	Red	<b>A side</b>	11	6	Orange	■ ■	Red	<b>A side</b>	21	11	Orange	■ ■ ■ ■	Red
	2			■	Black		12			■ ■	Black		22			■ ■ ■ ■	Black
	3	2	Light grey	■	Red		13	7	Light grey	■ ■	Red		23	12	Light grey	■ ■ ■ ■	Red
	4			■	Black		14			■ ■	Black		24			■ ■ ■ ■	Black
	5	3	White	■	Red		15	8	White	■ ■	Red		25	13	White	■ ■ ■ ■	Red
	6			■	Black		16			■ ■	Black		26			■ ■ ■ ■	Black
	7	4	Yellow	■	Red		17	9	Yellow	■ ■	Red						
	8			■	Black		18			■ ■	Black						
	9	5	Pink	■	Red		19	10	Pink	■ ■	Red						
	10			■	Black		20			■ ■	Black						

**Cable O.D.**

Product no.	Ø D
<b>LEC-CSNA-1</b>	11.1

**Dimensions/Pin No.**

Product no.	W	H	T	U	Pin no. n
<b>LEC-CSNA-1</b>	39	37.2	12.7	14	14

# LECY<sup>M</sup><sub>U</sub> Series

## Options

### MECHATROLINK cable type

**LEC-CY** **M** - **1**

**Motor type**

<b>Y</b>	AC servo motor
----------	----------------

**Cable description**

<b>M</b>	MECHATROLINK-II cable
<b>U</b>	MECHATROLINK-III cable

**Cable length (L)**


<b>L</b> <sup>*1</sup>	0.2 m
<b>J</b>	0.5 m
<b>1</b>	1 m
<b>3</b>	3 m

<sup>\*1</sup> Not available for the MECHATROLINK-II cable

\* LEC-CYM-□ is JEPMC-W6002-□□-E manufactured by YASKAWA CONTROLS CO., LTD.

\* LEC-CYU-□ is JEPMC-W6012-□□-E manufactured by YASKAWA CONTROLS CO., LTD.


### MECHATROLINK-II cable



#### Weight

Product no.	Length [m]	Weight [g]
<b>LEC-CYM-J</b>	0.5	50
<b>LEC-CYM-1</b>	1	80
<b>LEC-CYM-3</b>	3	200

### MECHATROLINK-III cable




#### Weight

Product no.	Length [m]	Weight [g]
<b>LEC-CYU-L</b>	0.2	21
<b>LEC-CYU-J</b>	0.5	41
<b>LEC-CYU-1</b>	1	75
<b>LEC-CYU-3</b>	3	205

### Terminating connector for MECHATROLINK-II

## LEC-CYRM

\* LEC-CYRM is JEPMC-W6022-E manufactured by YASKAWA CONTROLS CO., LTD.



Weight: 10 g




## Options



**LECYM2 LECYU2**  
Drivers



USB cable



PC

### Setup software (SigmaWin+™) (LECYM/LECYU common)

\* Please download the SigmaWin+™ via our website.  
SigmaWin+™ is a registered trademark or trademark of YASKAWA Electric Corporation.

**Adjustment, waveform display, parameter read/write, and test operation can be performed upon a PC.**

### Compatible PC

When using setup software (SigmaWin+™), use an IBM PC/AT compatible PC that meets the following operating conditions.

### Hardware Requirements

Equipment		Setup software (SigmaWin+™)
*1, 2, 3, 4 PC	OS	Windows® XP*5, Windows Vista®, Windows® 7 (32-bit/64-bit)
	Available HD space	350 MB or more (When the software is installed, 400 MB or more is recommended.)
	Communication interface	Use USB port.
Display	XVGA monitor (1024 x 768 or more, "The small font is used.") 256 colour or more (65536 colour or more is recommended.) Connectable with the PC above	
Keyboard	Connectable with the PC above	
Mouse	Connectable with the PC above	
Printer	Connectable with the PC above	
USB cable	LEC-JZ-CVUSB*6	
Other	Adobe Reader Ver. 5.0 or higher (* Except Ver. 6.0)	

- \*1 Windows, Windows Vista®, Windows® 7 are registered trademarks of Microsoft Corporation in the United States and/or other countries.
- \*2 On some PCs, this software may not run properly.
- \*3 Not compatible with 64-bit Windows® XP and 64-bit Windows Vista®
- \*4 For Windows® XP, please use it by the administrator authority (When installing and using it.)
- \*5 In PC that uses the program to correct the problem of HotfixQ328310, it is likely to fail in the installation. In that case, please use the program to correct the problem of HotfixQ329623.
- \*6 Order USB cable separately.


### Battery (LECYM/LECYU common)

## LEC-JZ-CVBAT

\* JZSP-BA01 manufactured by YASKAWA CONTROLS CO., LTD.

Battery for replacement

Absolute position data is maintained by installing the battery to the battery case of the encoder cable.



Weight: 10 g

\* The LEC-JZ-CVBAT is a single battery that uses lithium metal battery ER3V.

When transporting lithium metal batteries and devices with built-in lithium metal batteries by a method subject to UN regulations, it is necessary to apply measures according to the regulations stipulated in the United Nations Recommendations on the Transport of Dangerous Goods, the Technical Instructions (ICAO-TI) of the International Civil Aviation Organisation (ICAO), and the International Maritime Dangerous Goods Code (IMDG CODE) of the International Maritime Organisation (IMO). If a customer is transporting products such as shown above, it is necessary to confirm the latest regulations, or the laws and regulations of the country of transport on your own, in order to apply the proper measures. Please contact SMC sales representative for details.


### USB cable (2.5 m)

## LEC-JZ-CVUSB

\* JZSP-CVS06-02-E manufactured by YASKAWA CONTROLS CO., LTD.

Cable for connecting PC and driver when using the setup software (SigmaWin+™)

Do not use any cable other than this cable.



Weight: 150 g


### Cable for safety function device (3 m)

## LEC-JZ-CVSAF

\* JZSP-CVH03-03-E manufactured by YASKAWA CONTROLS CO., LTD.

Cable for connecting the driver and device when using the safety function

Do not use any cable other than this cable.



Weight: 160 g



# LECS□/LECS□-T/LECY□ Series Specific Product Precautions 1

Be sure to read this before handling the products. For safety instructions and electric actuator precautions, refer to the “Handling Precautions for SMC Products” and the “Operation Manual” on the SMC website: <https://www.smc.eu>

## Design / Selection

### Warning

- 1. Be sure to apply the specified voltage.**  
Otherwise, malfunction or breakage may occur. If the applied voltage is lower than the specified voltage, it is possible that the load will not be able to be moved due to an internal voltage drop of the driver. Please check the operating voltage before use.
- 2. Do not operate the product beyond the specifications.**  
Otherwise, a fire, malfunction, or actuator damage may result. Please check the specifications before use.
- 3. Install an emergency stop circuit.**  
Please install an emergency stop outside of the enclosure so that the system operation can be stopped immediately and the power supply can be intercepted.
- 4. In order to prevent any damage caused by the breakdown or malfunction of the driver and its peripheral devices, a backup system should be established in advance by giving a multiple-layered structure or a fail-safe design to the equipment, etc.**
- 5. If the danger of human injury is expected due to abnormal heat generation, smoking, ignition, etc., of the driver and its peripheral devices, cut off the power supply of the product and the system immediately.**
- 6. The parameters of the driver are set to initial values. Please change the parameters according to the specifications of the customer's equipment before use. Refer to the operation manual for parameter details.**

## Handling

### Warning

- 1. Do not touch the inside of the driver and its peripheral devices.**  
Doing so may cause an electric shock or damage to the driver.
- 2. Do not perform the operation or setting of the product with wet hands.**  
Doing so may cause an electric shock.
- 3. Products with damage or those missing any components should not be used.**  
An electric shock, fire, or injury may result.
- 4. Use only the specified combination between the electric actuator and the driver.**  
Failure to do so may cause damage to the actuator or the driver.
- 5. Be careful not to be hit by workpieces while the actuator is moving.**  
It may cause an injury.
- 6. Do not connect the power supply or power on the product before confirming the area to which the workpiece moves is safe.**  
The movement of the workpiece may cause an accident.
- 7. Do not touch the product when it is energised and for some time after the power has been disconnected, as it is very hot.**  
Doing so may lead to a burn due to the high temperature.
- 8. Before installation, wiring, and maintenance, the voltage should be checked with a tester 5 minutes after the power supply has been turned off.**  
Otherwise, an electric shock, fire, or injury may result.

## Handling

### Warning

- 9. Static electricity may cause a malfunction or break the driver. Do not touch the driver while power is supplied.**  
When touching the driver for maintenance, take sufficient measures to eliminate static electricity.
- 10. Do not use the product in an area where dust, powder dust, water, chemicals, or oil is in the air.**  
It will cause failure or malfunction.
- 11. Do not use the product in an area where a magnetic field is generated.**  
It will cause failure or malfunction.
- 12. Do not install the product in an environment containing flammable gas, explosive gas, or corrosive gas.**  
It could lead to fire, explosion, or corrosion.
- 13. Radiant heat from strong heat sources, such as a furnace, direct sunlight, etc., should not be applied to the product.**  
It will cause failure of the driver or its peripheral devices.
- 14. Do not use the product in an environment subject to a temperature cycle.**  
It will cause failure of the driver or its peripheral devices.
- 15. Do not use the product in a place where surges are generated.**  
When there are units that generate a large amount of surge around the product (e.g. solenoid type lifters, high-frequency induction furnaces, motors, etc.), this may cause deterioration or damage to the product's internal circuit. Avoid sources of surge generation and crossed lines.
- 16. Do not install the product in an environment under the effect of vibrations and impacts.**  
It will cause failure or malfunction.
- 17. When a surge-generating load, such as a relay or solenoid valve, is driven directly, use a product that incorporates a surge absorption element.**

## Installation

### Warning

- 1. Install the driver and its peripheral devices on a fire-proof material.**  
Direct installation on or near a flammable material may cause a fire.
- 2. Do not install the product in a place subject to vibrations and impacts.**  
It will cause failure or malfunction.
- 3. The driver should be mounted on a vertical wall in a vertical direction. Also, be sure not to cover the driver's suction/exhaust ports.**
- 4. Install the driver and its peripheral devices on a flat surface.**  
If the mounting surface is distorted or uneven, an unacceptable force may be added to the housing, etc., causing problems.



# LECS□/LECS□-T/LECY□ Series Specific Product Precautions 2

Be sure to read this before handling the products. For safety instructions and electric actuator precautions, refer to the “Handling Precautions for SMC Products” and the “Operation Manual” on the SMC website: <https://www.smc.eu>

## Power Supply

### ⚠ Caution

1. Use a power supply that has low noise between lines and between the power and ground.  
In cases where noise is high, an isolation transformer should be used.
2. To prevent lightning surges, appropriate measures should be taken. Ground the surge absorber for lightning separately from the grounding of the driver and its peripheral devices.

## Wiring


### ⚠ Warning

1. The driver will be damaged if a commercial power supply (100/200 V) is added to the driver's servo motor power (U, V, and W). Be sure to check wiring for mistakes when the power supply is turned on.
2. Connect the ends of the U, V, and W wires of the motor cable correctly to the phases (U, V, and W) of the servo motor power. If these wires do not match up, the servo motor cannot be controlled.

## Grounding

### ⚠ Warning

1. For grounding the actuator, connect the copper wire of the actuator to the driver's protective earth (PE) terminal and connect the copper wire of the driver to the earth via the control panel's protective earth (PE) terminal. Do not connect them directly to the control panel's protective earth (PE) terminal.




2. In the unlikely event that a malfunction is caused by the ground, please disconnect it.

## Maintenance

### ⚠ Warning

1. Perform a maintenance and inspection periodically.  
Confirm wiring and screws are not loose.  
Loose screws or wires may cause unintentional malfunction.
2. Conduct an appropriate functional inspection after completing the maintenance and inspection.  
At times where the equipment or machinery does not operate properly, conduct an emergency stop of the system. Otherwise, an unexpected malfunction may occur and it will become impossible to ensure safety. Conduct a test of the emergency stop in order to confirm the safety of the equipment.
3. Do not disassemble, modify, or repair the driver and its peripheral devices.
4. Do not put anything conductive or flammable inside the driver.  
It may cause a fire.
5. Do not conduct an insulation resistance test or withstand voltage test on this product.
6. Ensure sufficient space for maintenance activities.  
Design the system allowing the required space for maintenance and inspection.



**SMC Corporation (Europe)**

<b>Austria</b>	+43 (0)2262622800	www.smc.at	office@smc.at
<b>Belgium</b>	+32 (0)33551464	www.smc.be	info@smc.be
<b>Bulgaria</b>	+359 (0)2807670	www.smc.bg	office@smc.bg
<b>Croatia</b>	+385 (0)13707288	www.smc.hr	office@smc.hr
<b>Czech Republic</b>	+420 541424611	www.smc.cz	office@smc.cz
<b>Denmark</b>	+45 70252900	www.smcdk.com	smc@smcdk.com
<b>Estonia</b>	+372 6510370	www.smc pneumatics.ee	info@smcee.ee
<b>Finland</b>	+358 207513513	www.smc.fi	smc fi@smc.fi
<b>France</b>	+33 (0)164761000	www.smc-france.fr	info@smc-france.fr
<b>Germany</b>	+49 (0)61034020	www.smc.de	info@smc.de
<b>Greece</b>	+30 210 2717265	www.smchellas.gr	sales@smchellas.gr
<b>Hungary</b>	+36 23513000	www.smc.hu	office@smc.hu
<b>Ireland</b>	+353 (0)14039000	www.smcautomation.ie	sales@smcautomation.ie
<b>Italy</b>	+39 03990691	www.smcitalia.it	mailbox@smcitalia.it
<b>Latvia</b>	+371 67817700	www.smc.lv	info@smc.lv

<b>Lithuania</b>	+370 5 2308118	www.smclt.lt	info@smclt.lt
<b>Netherlands</b>	+31 (0)205318888	www.smc.nl	info@smc.nl
<b>Norway</b>	+47 67129020	www.smc-norge.no	post@smc-norge.no
<b>Poland</b>	+48 222119600	www.smc.pl	office@smc.pl
<b>Portugal</b>	+351 214724500	www.smc.eu	apoioclientept@smc.smces.es
<b>Romania</b>	+40 213205111	www.smcromania.ro	smcromania@smcromania.ro
<b>Russia</b>	+7 8123036600	www.smc.eu	sales@smcru.com
<b>Slovakia</b>	+421 (0)413213212	www.smc.sk	office@smc.sk
<b>Slovenia</b>	+386 (0)73885412	www.smc.si	office@smc.si
<b>Spain</b>	+34 945184100	www.smc.eu	post@smc.smces.es
<b>Sweden</b>	+46 (0)86031200	www.smc.nu	smc@smc.nu
<b>Switzerland</b>	+41 (0)523963131	www.smc.ch	helpcenter@smc.ch
<b>Turkey</b>	+90 212 489 0 440	www.smc pnomatik.com.tr	info@smc pnomatik.com.tr
<b>UK</b>	+44 (0)845 121 5122	www.smc.uk	sales@smc.uk