Fieldbus System

(For Input/Output)



Supports digital inputs/outputs, analog inputs/outputs, and IO-Link units

(New

An **OID**-Link unit compatible SI unit has been added (PROFINET).



<Compatible Protocols>

00.00

 Image: Property
 DeviceNet
 CC-Link
 IO-Link

 PROFIL
 EtherNet/IP
 EtherCAT. →

 Image: PowerLink
 CC-Línk IE Field

Please contact SMC for details on compatible products.

IO-Link unit

- 2 models (port class A and port class B)
- Diagnosis is possible from the upper level communication.
- The data can be accessed from via PC (setting tool).
- Device parameter setting function, Automatic saving/writing
- For the integrated SI unit, only PROFINET or EtherNet/IP[™] can be selected.
- PROFINET: Up to 9 IO-Link unit modules can be connected.
- EtherNet/IP™: Up to 4 IO-Link unit modules can be connected. (Made to order)

Self-diagnosis function

Equipped with an input/output open/shortcircuit detection function and an input/output signal ON/OFF counter function

Web server function*1

Status checks and forced output are possible via web browser.

 Parameter setting is only for EtherNet/IP[™].

A CONTRACTOR OF THE STREET

Various connectors available

The following connectors are selectable for the input/output devices: M12 connectors, M8 connectors, D-sub connectors, and spring type terminal blocks.


Up to 9 units^{*1} can be connected.


Up to 9 units can be connected in any order. *1 Excludes SI units



EX600 Series

Can be connected with digital, analog, and IO-Link units





Connectable Solenoid Valve/Vacuum Unit

Ameliaekle velve		Flow rate characteristics	$(4/2 \rightarrow 5/3)$	Max. number	Power consumption	Applicable
Applicable valve		C [dm³/(s⋅bar)]	b	of solenoids	[W]	cylinder size
	SY3000	1.6	0.19			ø50
	SY5000	3.6	0.17	32	0.35 (Standard) 0.1 (With power-saving circuit)	ø63
c FL us	SY7000	5.9	0.20			ø80
IP67 *1, *3	JSY1000	0.91	0.48		0.2 (With power-saving circuit)	ø40
	JSY3000	2.77	0.27	32	0.4 (Standard)	ø50
A LA COMPANY	JSY5000	6.59	0.22		0.1 (With power-saving circuit)	ø80
IP40 CE	S0700*2	0.37	0.39	32	0.35	ø25
	SV1000*2	1.1	0.35	32	0.6	ø40
A SHILL	SV2000*2	2.4	0.18			ø63
c AU us	SV3000*2	4.3	0.21			ø80
IP67 *1	VQC1000	1.0	0.30	24	0.4 (Standard)	ø40
CE	VQC2000	3.2	0.30			ø63
	VQC4000	7.3	0.38		0.95 (Standard)	ø160
· · · · · · · · · · · · · · · · · · ·	VQC5000	17	0.31		0.4 (Low-wattage type)	ø180
Applicable vacuum unit		Nozzle diamo [mm]	eter	Max. number of solenoids	Power consumption [W]	Max. vacuum pressure [kPa]
IP40		0.7				
		1.0		10		
	ZK2⊡A	1.2		16	0.4	-91
		1.5		1		

*1 Units with a D-sub communication connector are IP40.

*2 There is no manifold part number setting for the EX600-SPN3/4. (Order it separately.)

*3 The JSY1000 is IP40.


OIO-Link

IO-Link is a communication technology for sensors and actuators that is an international standard, IEC 61131-9.


This technology is used to send/receive device information such as manufacturer, product part number, parameters, and diagnostic data, as well as the control data including ON/OFF signals and measured values of the sensor, by connecting the IO-Link master and device in a 1:1 configuration.

IO-Link enables condition monitoring and error detection of the sensor and equipment, and it can contribute to the reduction of startup labor and recovery time and the realization of preventive and predictive maintenance.

Reduced design and startup labor	 Batch setting of device parameters from the upper level Remote check of device information Detection and remote unified check of device misconnection/non-connection
Minimum recovery time due to error detection	 Early detection of location where problem is occurring via communication Early obtaining of information on problem phenomenon via communication Early recovery during product replacement (automatic setting of device parameters)
Preventive and predictive maintenance through condition monitoring	 Monitors changes in measured values of a sensor during signal ON/OFF Monitors the number of device operations and automatically notifies when the set number of operations has been exceeded Remote monitoring of device and equipment conditions via communication



IO-Link System Configuration



10-Link unit

Acts as a gateway between the IO-Link
 communication and the upper level communication

2 IO-Link device

• A sensor/actuator connecting to each port of the IO-Link unit in a 1:1 configuration

3 IODD file

- A file in which device properties and parameters are described
- Registered to the setting tool
- · Provided by the device manufacturer

4 Communication cable


- A 4-wire or 5-wire general-purpose cable that is the
- same as the existing sensor cable (Unshielded cable) • Max. cable length: 20 m

5 IO-Link setting tool software

- Software for the setting and monitoring of an IO-Link unit/device
- *1 A setting tool compatible with the IO-Link units of every manufacturer is used for the SMC EX600 series IO-Link unit. (IO-Link Device Tool V5 manufactured by TMG Technologie und Engineering, Germany)


IO-Link Interface


The connecting part between the IO-Link unit and the device is called a "port." Each port can be switched between "IO-Link mode" for digital communication and "standard I/O mode" for conventional contact input/ output.




2 types of interfaces

There are two methods for power supply: one is for sensors, and the other is for actuators.






The control power supply wire and signal wire can be connected with one cable. (Mainly for sensors)



IO-Link Unit

Can be connected with digital, analog, and IO-Link unit units


PROFINET: Up to 9 IO-Link units can be connected. (Total of 36 ports) EtherNet/IP™: Up to 4 IO-Link units can be connected. (Total of 16 ports) Digital units, analog units, and IO-Link units can be mixed, and up to 9 units can be connected in any order.



Supports both port class A and port class B





For connecting IO-Link sensors Pressure sensors, flow sensors, actuator position sensors, electro-pneumatic regulators, etc.



For connecting IO-Link compatible SI units (for valve driving)

The data can be accessed from via PC (setting tool).





The setting and monitoring of the IO-Link unit and device are possible via PC, without using the PLC. • Process data

- Device parameters, IO-Link unit parameters
- IO-Link unit information, Device information
- Port diagnosis, Device diagnosis


* The PC setting tool is an IO-Link device tool manufactured by Technologie Management Gruppe (hereinafter referred to as TMG). It can be downloaded for free from the TMG website, however, for usage beyond 30 days, a license key is required.



Diagnosis function

Diagnosis is possible from the upper level communication.

IO-Link unit (port) diagnostic information can be obtained via PLC program or PC (web browser). Device diagnostic information can be obtained via PC (setting tool).




Items of IO-Link unit (port) diagnosis
Detection of port short-circuit
Detection of non-connected device
Detection of misconnected device (check error)
Notification of port misconfiguration (excessively large input/output data)
Conditions of diagnostic event (port, device)
Items of device diagnosis

Diagnostic results (problem phenomenon) received from devices are shown in event codes.

Device parameter setting function, Automatic saving/writing

The parameter setting of devices is possible from the upper level communication.


Parameter setting is possible via PC (setting tool). It is also possible to use output data or message data via PLC program.



EtherNet Fieldbus Functions


PROFINET (EX600-SPN3/4) and EtherNet/IP[™] (EX600-SEN3/4) support the following functions.

Compatible topologies (Connection configuration)



For ring networks, communication can be continued even if one of the communication cables in the network is disconnected or damaged. As the EX600-SEN3/4 supports Device Level Ring (DLR), and the EX600-SPN3/4 supports Media Redundancy Protocol (MRP), the disconnected point can be identified.

* In order to use DLR or MRP, the PLC must be able to support it.



■ Supports the QuickConnect[™] function and the Fast Start Up function

Time from power ON Greatly reduces the communication to communication connection connection time Appro 10 s In the case of a tool changer, it takes about 10 seconds for communication to be connected in some products after Robot arm Tool 2 Tool 3 the power to the device installed on the EX600 tool is turned ON. As the EX600-SEN3/4 supports the QuickConnect[™] function, and the Tool 1 EX600-SPN3/4 supports the Fast Start EX600 EX600 Up function, communication connection in only approx. 0.5 s is possible. * In order to use the QuickConnect[™] function or the Fast Start Up function, the PLC must be able to support it. PLC Built-in web server function EX600 1 to 3 can be accessed via a The EX600-SEN3/4 and EX600web browser. SPN3/4 have a built-in web server function, which enables status checks. EX600-SEN3/4. EX600-SPN3/4

Switching hub

EX6001

EX600 **2** Connection example


parameter settings (EX600-SEN3/4 only), and forced output of the EX600 using general-purpose web browsers, such as Microsoft Edge. Start-up of the system and maintenance can be performed efficiently.

Latest PROFINET Technology

System Redundancy S2

As the EX600-SPN3/4 supports System Redundancy S2, it can continue communication using the backup controller when the primary controller malfunctions. This allows for the prevention of problems caused by unexpected communication interruption.

* In order to use System Redundancy S2, the PLC must be able to support this function.



EX6003

Status check

· Parameter setting

Forced output, etc.

Fieldbus System EX600

D-sub connector


IP40

These units are capable of connection using a D-sub connector. There are three types of units: for digital input, output, and input/output. The digital output unit can be connected with an SMC manifold solenoid valve F kit (D-sub connector).

Manifold solenoid valves/Vacuum unit can be connected using a cable with a D-sub connector. SQ series SJ series

- SY series S0700 series VQC series
- SV series
- VQ series
- ZK2 A series
- JSY series
- Please limit the number of valve connections to 16 stations for single and 8 stations for double. Refer to the catalog of each product for pin assignment details.


VVZS3000-21A--X192 (Non-waterproof cable example)



Spring type terminal block




These terminal block units are compatible with individual wiring configurations. There are three types of units: for digital input, output, and input/output. Wiring connection to a sensor connector box, etc., can be carried out easily using only a flat head screwdriver.



Digital input unit




This unit is for inputting a digital signal (ON/OFF signal). The signal of a 2-wire/3-wire auto switch attached to the actuator can be acquired to feedback a signal to the PLC. The control signal of an entire system can be managed by a Fieldbus system.



Analog input/output unit



These units are for inputting or outputting an analog signal (voltage/current). A single unit performs both input and output, allowing feedback control where analog signals are received from a pressure sensor and sent to a pressure controller. Installation space is minimized as well.



Self-diagnosis function

The following shows examples of the self-diagnosis function.

Short/Open-circuit detection

It is possible to detect short or open circuits of input devices such as electronic 2-wire switches and 3-wire switches and output devices such as solenoid valves. The location of the error can be identified by the indicator light and the network.



Counter function

It is possible to ascertain the maintenance period and identify the parts that require maintenance by an input and output signal ON/OFF counter function. When the counter function is enabled and a certain number of contact operations is reached, the display of the counter will flash in red.


* The counter function is not provided with analog units.

Individual units can be connected and removed one by one.

A unique clamping method is adopted to prevent screws from falling out. Units can be separated easily by loosening the joint bracket.

Up to 9 units can be connected in any order.

* Excludes SI units






CONTENTS

Type 3 Integrated input-output type

Fieldbus System (For Input/Output) *EX600 Series*







	3
SMC Digital IN	
0 40 50 60 70	I
0 80 90 100 110	
120 130 140 150	
	-111
	=
°	
0	=111
	3
	2

Parts Structure ······p. 1	2
How to Order	
SI Unit ······p. 1	
Digital Input Unit ······p. 1	3
Digital Output Unitp. 1	
Digital Input/Output Unit ····· p. 1	3
Analog Input Unit ······p. 1	3
Analog Output Unitp. 1	3
Analog Input/Output Unitp. 1	4
IO-Link Unit ······p. 1	
End Plate (D side)p. 1	4
Handheld Terminalp. 1	4
Specifications	
All Units Commonp. 1	
SI Unit ······p. 1	
Digital Input Unit ······p. 1	8
Digital Output Unitp. 1	
Digital Input/Output Unit ····· p. 1	
Analog Input Unitp. 2	
Analog Output Unitp. 2	
Analog Input/Output Unitp. 2	
IO-Link Unit ······p. 2	22
End Plate ······p. 2	22
Handheld Terminal	22
Dimensions ······p. 2	23
Parts Descriptionp. 2	27
LED Indicator ······p. 2	29


Accessories

End Plate Bracket p. 33
2 Valve Plate
3 End Plate (U side) p. 34
Reinforcing Brace
5 Seal Cap (10 pcs.) p. 34
6 Marker (1 sheet, 88 pcs.) p. 34
Power Supply Cable (7/8 inch connector) p. 35
8 Power Supply Field-wireable
Connector (7/8 inch) ····· p. 35
Power Supply Cable
(M12 connector, For EX600-ED2) ······p. 35
Power Supply Cable
(M12 connector, For EX600-ED4/5)p. 36
Communication Cable p. 37
Pield-wireable Communication Connector p. 42
I/O Cable with Connector, I/O Connector p. 43

Made to Order

① Ethernet POWERLINK compatible ······ p. 44
2 Modbus/TCP compatiblep. 44
③CC-Link IE Field compatiblep. 44
Communication Cable p. 45


Specific Product Precautions ······p. ·	46
---	----



How to Order

SI Unit

EX600-SPR1A-




			Specifications
Symbol	Protocol	Output type	Note
PR1A	PROFIBUS DP	PNP (Negative common)	—
PR2A	FROFIDUS DF	NPN (Positive common)	—
DN1A	DeviceNet®	PNP (Negative common)	—
DN2A	Devicemet	NPN (Positive common)	—
MJ1	CC-Link	PNP (Negative common)	—
MJ2	CO-LINK	NPN (Positive common)	—
CF1-X60	CC-Link IE Field	PNP (Negative common)	(Made to order)
EN1		PNP (Negative common)	1 port
EN2		NPN (Positive common)	1 port
EN3	EtherNet/IP™	PNP (Negative common)	2 ports
EN4	EmerneviP	NPN(Positive common)	2 ports
EN3-X80		PNP (Negative common)	IO-Link unit (Made to order)
EC1	EtherCAT	PNP (Negative common)	—
EC2	LUIEICAT	NPN (Positive common)	—
PN1		PNP (Negative common)	—
PN2	PROFINET	NPN (Positive common)	—
PN3		PNP (Negative common)	IO-Link unit
PN4		NPN (Positive common)	IO-Link unit

Made to order

(Refer to page 44.)
Ethernet POWERLINK
Modbus TCP
CC-Link IE Field
NPN (Positive common)

	How to Order	
Digital Input Unit	EX600-DXP	D
	Input type Symbol Description P PNP N NPN	Number of inputs, open-circuit detection, and connectorSymbolNumber of inputsOpen-circuit detectionConnectorB8 inputsNoM12 connector (5 pins) 4 pcs.C8 inputsNoM8 connector (3 pins) 8 pcs.C18 inputsNoM12 connector (5 pins) 8 pcs.D16 inputsNoM12 connector (5 pins) 8 pcs.E16 inputsNoD-sub connector (25 pins)F16 inputsNoSpring type terminal block (32 pins)
Digital Output Unit	EX600-DY Output type Symbol Description P PNP N NPN	Symbol Number of outputs and connector Symbol Number of outputs Generation Connector B 8 outputs M12 connector (5 pins) 4 pcs. E 16 outputs D-sub connector (25 pins) F 16 outputs Spring type terminal block (32 pins)
Digital Input/Output Unit	EX600-DM Input/Output type	Symbol Number of inputs/outputs and connector Symbol Number of outputs Connector Connector E 8 inputs 8 outputs F 8 inputs 8 outputs Spring type terminal block (32 pins)
Analog Input Unit	EX600 – AX A Analog input	umber of input channels and connectorNumber of input channelsConnector2 channelsM12 connector (5 pins) 2 pcs.
Analog Output Unit	EX600 – AY A Analog output	umber of output channels and connectorNumber of output channelsConnector2 channelsM12 connector (5 pins) 2 pcs.

Fieldbus System For Input/Output **EX600** Series



Specifications

All Units Common Specifications

ŝnt	Operating temperature range	Operating: -10 to 50°C, Stored: -20 to 60°C
Ĕ	Operating humidity range	35 to 85% RH (No condensation)
5	Withstand voltage*1	500 VAC for 1 minute between external terminals and FE
Ē	Insulation resistance*1	500 VDC, 10 M Ω or more between external terminals and FE

Environment *1 Except handheld terminals

SI Unit (EX600-SPR

<u> </u>				
	Model	EX600-SPR1A	EX600-SPR2A	
ы	Protocol	PROFIBUS DP (DP-V0)		
Device type		PROFIBUS	S DP Slave	
Communication speed		9.6/19.2/45.45/93.75/187.5	/500 kbps 1.5/3/6/12 Mbps	
n	Configuration file	GSD	file*2	
Device type Communication speed Configuration file Occupation area O(Number of inputs/outputs)		Max. (512 inputs/512 outputs)		
Те	rminating resistor	Internally in	nplemented	
Internal current consumption (Power supply for Control/Input)		80 mA or less		
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)	
+	Number of outputs	32 outputs (8/16/24/3	2 outputs selectable)	
Output	Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC)		
<u>t</u>	Power supply	24 VD	C, 2 A	
	Fail safe	HOLD/CLEAR/Forced power ON		
Protection		Short-circuit protection		
En	closure	IP67 (Manifold assembly)		
St	andards	CE marking (EMC directive/RoHS directive), UL (CSA)		
W	eight	300	0 g	
-				

*2 The configuration file can be downloaded from the SMC website: https://www.smcworld.com

SI Unit (EX600-SDN A)


<u> </u>						
	Model	EX600-SDN1A	EX600-SDN2A			
	Protocol	DeviceNet [®] : Volume 1 (Edition 2.1), Volume 3 (Edition 1.1)				
c	Device type	Group 2 O	nly Server			
₽	Communication speed	125/250/	500 kbps			
ica –	Configuration file	EDS	file*3			
ommunicatio	Occupation area (Number of inputs/outputs)	Max. (512 inpu	ts/512 outputs)			
Соп	Applicable messages	Duplicate MAC ID Check Message, Group 2 Only Unconnected Explicit Message Explicit Message (Group 2), Poll I/O Message (Predefined M/S Connection set)				
	Applicable function	QuickCo	nnect™			
De	viceNet [®] power supply	11 to 25 VDC (Current consumption 50 mA or less)				
	ernal current consumption ower supply for Control/Input)	55 mA or less				
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)			
-	Number of outputs	32 outputs (8/16/24/32 outputs selectable)				
put	Load	Solenoid valve with surge voltage sup	pressor 24 VDC, 1.5 W or less (SMC)			
Out	Power supply	24 VD	C, 2 A			
	Fail safe	HOLD/CLEAR/Forced power ON				
	Protection	Short-circuit protection				
Er	closure	IP67 (Manifold assembly)				
St	andards	CE marking (EMC directive/RoHS directive), UL (CSA)				
W	eight	300 g				
-						

*3 The configuration file can be downloaded from the SMC website: https://www.smcworld.com


SI Unit (EX600-SMJ

	Model	EX600-SMJ1	EX600-SMJ2	
		CC-Link (Ver. 1.10, Ver. 2.00)		
Station type		Remote De	· · · · ·	
Communication speed		156/625 kbps	2.5/5/10 Mbps	
Configuration file Occupation area Max. (CSP+	file*4	
		Max. (512 inpu 1/2/3/4 statio	ts/512 outputs) ons occupied	
Int (Pc	ernal current consumption ower supply for Control/Input)	75 mA or less		
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)	
+	Number of outputs	32 outputs (8/16/24/3	2 outputs selectable)	
Output	Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC)		
T	Power supply	24 VDC, 2 A		
0	Fail safe	HOLD/CLEAR/Forced power ON		
	Protection	Short-circuit protection		
En	closure	IP67 (Manifold assembly)		
St	andards	CE marking (EMC directive/RoHS directive), UL (CSA)		
W	eight	30	0 g	


*4 The configuration file can be downloaded from the SMC website: https://www.smcworld.com



EX600-SPR




EX600-SDN



EX600-SMJ



Specifications



EX600-SCF1-X60

	Model	EX600-SCF1-X60*1	
	Protocol	CC-Link IE Field	
	Station type	Intelligent Device Station	
E	Communication speed	1 Gbps	
tio	Allowable station number setting	1 to 120	
ica	Allowable network number setting	1 to 239	
n	Transmission method	Cyclic transmission	
E	Configuration file	CSP+ file*2	
Communication	Occupied input size	RX: 32 to 176 bits	
	Occupied input size	RWr: 32 to 608 words	
	Occupied output size	RY: 32 to 176 bits	
	Occupied output size	RWw: 32 to 608 words	
	ernal current consumption ower supply for Control/Input)	140 mA or less	
	Output type	Source/PNP (Negative common)	
	Number of outputs	32 outputs	
rt	Load	Solenoid valve with surge voltage suppressor	
Output	Luau	24 VDC, 1.0 W or less (SMC)	
Ō	Power supply	24 VDC, 2 A	
	Fail safe	HOLD/CLEAR/Forced power ON	
	Protection	Short-circuit protection	
Er	nclosure	IP67 (Manifold assembly)	
St	andards	CE marking (EMC directive/RoHS directive)	
W	eight	300 g	

*1 For details on this product, refer to the SMC website.

*2 The configuration file can be downloaded from the SMC website: https://www.smcworld.com

The 1-port EtherNet/IP compatible SI unit is to be discontinued as of March 2022.				
to be discontinued as d	DT IV	larch 2022.		
Please consider ordering	ng	the 2-port EtherNet/		
IP compatible SI unit as	s a	substitute.		
Discontinued models		Substitute models		
EX600-SEN1	►	EX600-SEN3		
EX600-SEN2	►	EX600-SEN4		


SI Unit (EX600-SEND)

SI Unit (EX600-SCF1-X60)


Model		EX600-SEN1	EX600-SEN2	EX600-SEN3	EX600-SEN4	EX600-SEN3-X80
	Number of communication ports	1 p	ort	2 ports		
	Protocol	EtherNe	EtherNet/IP™ EtherNet/IP™			
	Protocol	(Conformance vers	ion: Composite 6)	(Conforma	nce version: Cor	nposite 11)
	Communication speed	10/100 Mbps				
	Communication method		Ful	l duplex/Half dup	lex	
5	Configuration file			EDS file ^{*3}		
Communication	Occupation area (Number of inputs/outputs)		Max. (512 inputs/512 or	utputs)	
nmm	IP address setting range			ettings: 192.168 CP server: Optio		
ပီ		Vendor ID: 7 (SN	IC Corporation)	Vendor	ID: 7 (SMC Corp	oration)
	Device information	Device type: 12 (Communication Adapter)			12 (Communica	. ,
		Product code: 126		Product code: 203		3
	QuickConnect		-			•
	DLR		-	$\bullet \qquad \bullet$		•
	Web server function	—		•		•
10-	Link unit	_				
	ernal current consumption wer supply for Control/Input)	120 mA or less				
	Output turns	Source/PNP	Sink/NPN	Source/PNP	Sink/NPN	Source/PNP
	Output type	(Negative common)	(Positive common)	(Negative common)	(Positive common)	(Negative common)
.	Number of outputs	32 outputs (8/16/24/32	2 outputs selectable)	32 outputs		
Output	Load	Solenoid valve with surg			with surge volta	
5	Loau	24 VDC, 1.5 W	or less (SMC)	24 VDC, 1.0 W or less (SMC)		
	Power supply			24 VDC, 2 A		
	Fail safe	HOLD/CLEAR/Forced power ON				
	Protection	Short-circuit protection				
En	closure	IP67 (Manifold assembly)				
Sta	andards	CE	marking (EMC	directive/RoHS d	irective), UL (CS	SA)
We	eight			300 g		

*3 The configuration file can be downloaded from the SMC website: https://www.smcworld.com

SMC




EX600-SEN1/2



EX600-SEN3/4(-X80)

Specifications




EX600-SEC

	Model	EX600-SEC1	EX600-SEC2		
5 Protocol		EtherCAT (Conforman	EtherCAT (Conformance Test Record V.1.2)		
cati	Communication speed	100 N	Abps		
ini	Configuration file	XML	file*1		
Communication	Occupation area (Number of inputs/outputs)	Max. (512 inputs/512 outputs)			
	ernal current consumption wer supply for Control/Input)	100 mA or less			
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)		
+	Number of outputs	32 outputs (8/16/24/32 outputs selectable)			
Output	Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC)			
<u>d</u>	Power supply	24 VD	C, 2 A		
Ŭ	Fail safe	HOLD/CLEAR/Forced power ON			
	Protection	Short-circuit protection			
En	closure	IP67 (Manifold assembly)			
St	andards	CE marking (EMC directive/RoHS directive), UL (CSA)			
Weight 300 g) g		


*1 The configuration file can be downloaded from the SMC website: https://www.smcworld.com

SI Unit (EX600-SPN□)




*2 The configuration file can be downloaded from the SMC website: https://www.smcworld.com

EX600-SPN1/2



EX600-SPN3/4

Specifications



EX600-DX


Digital Input Unit

Model		EX600-DXPB	EX600-DXNB	EX600-DXPC	EX600-DXNC	EX600-DXPD	EX600-DXND	
	Input type		PNP	NPN	PNP	NPN	PNP	NPN
	Input connecto	r	M12 (5-pir	n) socket*1	M8 (3-pin) socket*3	M12 (5-pir	n) socket*1
	Number of inpu	uts	8 inputs (2 inp	uts/Connector)	8 inputs (1 inp	out/Connector)	16 inputs (2 inp	outs/Connector)
	Supplied voltage	ge			24 \	/DC	<u>`</u>	
	Max. supplied current			onnector Unit	0.25 A/Connector 2 A/Unit			onnector Unit
Protection		Short-circuit protection						
⊑	Input current (at	24 VDC)	9 mA or less					
	ON voltage		17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)					
	OFF voltage		5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)					
	Open circuit	2 wires	-		0.5 mA	/Input*2	-	-
	detection current 3 wires		-	_	0.5 mA/Co	onnector*2	-	-
Сι	irrent consumpt	ion	50 mA	or less	55 mA	or less	70 mA	or less
Enclosure			IP67 (Manifold assembly)					
St	andards		CE marking (EMC directive/RoHS directive), UL (CSA)					
W	eight		30	0 g	27	5 g	34	0 g


*1 M12 (4-pin) connector can be connected.
*2 Function only applies to the EX600-DX□C1.
*3 When connecting the M8 plug connector, the tightening torque must be 0.2 N·m ±10%. If tightened with an excessive tightening torque, this may cause the connector thread of the unit to break.

	Model	EX600-DXPE	EX600-DXNE	EX600-DXPF	EX600-DXNF		
	Input type	PNP	NPN	PNP	NPN		
	Input connector	D-sub sock Lock screw: I	et (25 pins) No.4-40 UNC	Spring type terminal block (32 pins)			
	Number of inputs	16 ir	nputs	16 inputs (2 inp	outs x 8 blocks)		
	Supplied voltage		24 \	/DC			
Input	Max. supplied current	2 A/	2 A/Unit		/Block /Unit		
1	Protection		Short-circuit protection				
	Input current (at 24 VDC)		5 mA (or less			
	ON voltage	· ·	17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)				
	OFF voltage	5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +2 (At PNP input, between the pin for input terminal and supplied voltage of 0 V)					
Ap	plicable wire	—		0.08 to 1.5 mm ² (AWG16 to 28)			
Cu	irrent consumption	50 mA	or less	55 mA or less			
En	closure	IP40 (Manifold assembly)					
St	andards	CE marking (EMC directive/RoHS directive), UL (CSA)					
W	eight	300 g					

Specifications



EX600-DY□E EX600-DM□E



EX600-DY⊡F EX600-DM⊡F

Digital Output Unit


	Model	EX600-DYPB	EX600-DYNB	EX600-DYPE	EX600-DYNE	EX600-DYPF	EX600-DYNF	
	Output type	PNP	NPN	PNP	NPN	PNP	NPN	
	Output connector	M12 (5-pir	M12 (5-pin) socket*1		D-sub socket (25 pins) Lock screw: No.4-40 UNC		Spring type terminal block (32 pins)	
Number of outputs Supplied voltage		8 outputs (2 out	puts/Connector)	16 ou	utputs	16 outputs (2 ou	tputs x 8 blocks)	
Out	Supplied voltage			24 \	/DC			
	Max. load current		0.5 A/Output 2 A/Unit					
	Protection			Short-circuit protection				
Ap	oplicable wire	-			_	0.08 to 1.5 mm ² (AWG16 to 28)		
Сι	Irrent consumption	50 mA or less						
Enclosure		IP67 IP40 (Manifold assembly) (Manifold assembly)						
St	andards	CE marking (EMC directive/RoHS directive), UL (CSA)						
W	eight	300 g						

*1 M12 (4-pin) connector can be connected.

Digital Input/Output Unit

_							
	Model	EX600-DMPE	EX600-DMNE	EX600-DMPF	EX600-DMNF		
In	put/Output type	PNP	NPN	PNP	NPN		
Connector		D-sub sock Lock screw: I	· · · /	Spring type termin	nal block (32 pins)		
	Number of inputs	8 in	outs	8 inputs (2 inp	uts x 4 blocks)		
	Supplied voltage		24 \	/DC			
Input	Max. supplied current	2 A/	Unit		′Block ′Unit		
	Protection	Short-circuit protection					
	Input current (at 24 VDC)		5 mA	or less			
	ON voltage	17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)					
	OFF voltage	5 V or less (At NPN input, between the pin for input terminal and supplied voltage (At PNP input, between the pin for input terminal and supplied voltage of 0					
	Number of outputs	8 out	8 outputs 8 outputs (2 outputs x 4				
Ħ	Supplied voltage	24 VDC					
Output	Max. load current			V/Output A/Unit			
	Protection	Short-circuit protection					
Applicable wire		_	_	0.08 to 1.5 mm ² (AWG16 to 28)			
С	urrent consumption	50 mA	or less	60 mA	or less		
Er	nclosure	IP40 (Manifold assembly)					
St	andards	CE marking (EMC directive/RoHS directive), UL (CSA)					
W	eight	300 g					

Specifications



EX600-AXA

Analog Input Unit


Model			EX600	ΑΧΑ	
	Input type		Voltage input	Current input	
	Input conn	ector	M12 (5-pin) socket*1	
	Input chan	nel	2 channels (1 cha	annel/Connector)	
	Supplied v	oltage	24 V	/DC	
	Max. suppl	ied current	0.5 A/Cc	nnector	
÷	Protection		Short-circui	t protection	
Input	Input	12 bit resolution	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA	
-	signal range	16 bit resolution	-10 to 10 V, -5 to 5 V	-20 to 20 mA	
	Max. rated input signal		±15 V	±22 mA*2	
	Input impedance		100 kΩ	50 Ω	
	Linearity (2	25°C)	±0.05% F.S.		
	Repeatabil	ity (25°C)	±0.15% F.S.		
	Absolute ac	curacy (25°C)	±0.5% F.S.	±0.6% F.S.	
Cu	irrent consu	Imption	70 mA or less		
En	closure		IP67 (Manifold assembly)		
Standards			CE marking (EMC directive/RoHS directive), UL (CSA)		
Weight			290) g	

*1 M12 (4-pin) connector can be connected.
*2 When input signal exceeds 22 mA, the protection function activates and the input signal is interrupted.

Analog Output Unit


	Mod	el	EX600-AYA		
	Output typ	e	Voltage output	Current output	
	Output con	nector	M12 (5-pir	n) socket*3	
	Output cha	innel	2 channels (1 cha	annel/Connector)	
	Supplied v	oltage	24 \	/DC	
	Max. load current		0.5 A/Co	onnector	
put	Protection		Short-circui	t protection	
Output	Output signal range	12 bit resolution	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA	
	Load impedance		1 k Ω or more	600 Ω or less	
	Linearity (25°C)		±0.05% F.S.		
	Repeatability (25°C)		±0.159	% F.S.	
	Absolute accuracy (25°C)		±0.5% F.S.	±0.6% F.S.	
Сι	urrent consu	Imption	70 mA or less		
Enclosure			IP67 (Manifold assembly)		
Standards			CE marking (EMC directive/RoHS directive), UL (CSA)		
W	eight		290	0 g	

*3 M12 (4-pin) connector can be connected.



EX600-AYA

Specifications




EX600-AMB

Analog Input/Output Unit

Model		EX600	-AMB	
	Input type	Voltage input	Current input	
	Input connector	M12 (5-pin		
	Input channel	2 channels (1 channel/Connector)		
	Supplied voltage	24 VDC		
	Max. supplied current	0.5 A/Co	onnector	
	Protection	Short-circui	t protection	
Input	Input signal range	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA	
	Max. rated input signal	15 V	22 mA*2	
	Input impedance	100 kΩ	250 Ω	
	Linearity (25°C)	±0.05%	% F.S.	
	Repeatability (25°C)	±0.15%	% F.S.	
	Absolute accuracy (25°C)	±0.5% F.S.	±0.6% F.S.	
	Output type	Voltage output	Current output	
	Output connector	M12 (5-pin) socket*1		
	Output channel	2 channels (1 channel/Connector)		
	Supplied voltage	24 VDC		
	Max. load current	0.5 A/Connector		
Output	Protection	Short-circui	t protection	
Ō	Output 12 bit resolution	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA	
	Load impedance	1 k Ω or more	600 Ω or less	
	Linearity (25°C)	±0.05%	% F.S.	
	Repeatability (25°C)	±0.15%	% F.S.	
	Absolute accuracy (25°C)	±0.5% F.S.	±0.6% F.S.	
C	urrent consumption	100 mA	or less	
Er	nclosure	IP67 (Manifo	ld assembly)	
St	andards	CE marking (EMC directive/	/RoHS directive), UL (CSA)	
w	eight	300) g	


*1 M12 (4-pin) connector can be connected.
*2 When input signal exceeds 22 mA, the protection function activates and the input signal is interrupted.


Specifications




EX600-L□B1

Model		EX600	-LAB1	EX600-LBB1	
IO-Link version		Version 1.1			
10	-Link port class	Clas	ss A	Class B	
Communication speed		COM1 (4.8 kBaud) COM2 (38.4 kBaud) COM3 (230.4 kBaud) * Changes automatically according to the connected device			
Nι	mber of IO-Link ports			4	
	ompatible SI unit rotocol)			4 (PROFINET) 0 (EtherNet/IP™)	
Max. supply current	Device power supply (L+)	0.5 A/Co (2 A/		0.5 A/Connector (1 A/Unit)	
Max. supp	External power supply (P24)	—		1.6 A/Connector (3 A/Unit)	
	Pin no.	2	4	4	
	Input type		19	NP	
Indu	Protection		Short-circu	it protection	
É	Rated input current	Approx. 2.5 mA		Approx. 5.8 mA	
	ON voltage		13 V o	r more	
	OFF voltage		8 V o	r less	
	Pin no.			1	
۶l	Output type		PI	NP	
output	Max. load current (C/Q line)	0.25 A/Output (Supplied from the power supply for control/input)			
	Protection	Short-circuit protection			
Ci	irrent consumption	50 mA or less			
Er	closure		IP67 (Manifo	ld assembly)	
Standards		CE marking (EMC directive/RoHS directive), UL (CSA)			
3			320 g		






EX600-ED2-







EX600-ED3-



EX600-HT1A-

End Plate

Model			EX600-ED2-	EX600-ED2-🗆 EX600-ED3-🗆 EX600-EI			
su	Power supply	PWR IN	M12 (5-pin) plug	7/8 inch (5-pin) plug	M12 (4-pin) plug		
specifications	connector	PWR OUT	—	—	M12 (5-pin) socket		
cific	Rated	Power supply for control/input		24 VDC ±10%			
	voltage	Power supply for output		24 VDC +10/-5%			
Power	Rated	Power supply for control/input	Max 2 A	Max. 8 A	Max. 4 A		
R	current	Power supply for output	Max. 2 A	Max. o A	Max. 4 A		
Enclosure			IP67 (Manifold assembly)				
Standards*1		CE marking (EMC directive/RoHS directive), UL (CSA)					
Weight			170 g	175 g	170 g		

*1 The EX600-ED4/5- \square is not compliant with UL (CSA) standards.


Handheld Terminal

EX600-HT1A-🗆
Power supplied from SI unit connector (24 VDC)
50 mA or less
LCD with backlight
Handheld terminal cable (1 m ··· EX600-AC010-1, 3 m ··· EX600-AC030-1)
IP20
CE marking (EMC directive/RoHS directive)
160 g


*1 The handheld terminal is not compliant with UL (CSA) standards. * Cannot be used with the EX600-SPN3/4 and EX600-LAB1/LBB1




Dimensions





EX600-SPN3/4


















Dimensions



M12 5-pin plug, B-coded

Configuration	E	X600-ED2
Configuration	Pin no.	Description
	1	24 V (for output)
2	2	0 V (for output)
5(0)	3	24 V (for control/input)
3 4	4	0 V (for control/input)
	5	FE

M12 4-pin plug, A-coded

Configuration	EX600-1	X600-ED4 (Pin arrangement 1)		EX600-ED5 (Pin arrangement 2)	
Conniguration	Pin no.	Description	Pin no.	Description	
3 - 2	1	24 V (for control/input)	1	24 V (for output)	
60	2	24 V (for output)	2	0 V (for output)	
$ \circ \circ $	3	0 V (for control/input)	3	24 V (for control/input)	
4 1	4	0 V (for output)	4	0 V (for control/input)	


M12 5-pin socket, A-coded


Configuration	EX600-ED4 (Pin arrangement 1)		EX600-ED5 (Pin arrangement 2)	
Configuration	Pin no.	Description	Pin no.	Description
1 2	1	24 V (for control/input)	1	24 V (for output)
60	2	24 V (for output)	2	0 V (for output)
	3	0 V (for control/input)	3	24 V (for control/input)
4 5 3	4	0 V (for output)	4	0 V (for control/input)
. 5 0	5	Unused	5	Unused




Dimensions

End Plate (D side) EX600-ED3





5.5




Power supply connector PWR: 7/8 inch 5-pin plug


Configuration	Pin no.	Description
	1	0 V (for output)
	2	0 V (for control/input)
2	3	FE
	4	24 V (for control/input)
3	5	24 V (for output)

Dimensions


Digital Unit


















EX600-DX□C□

EX600-DXDD












EX600-DX□F EX600-DY□F EX600-DM□F









Fieldbus System For Input/Output **EX600** Series

Dimensions


Analog Unit


EX600-AXA EX600-AYA






EX600-AMB










IO-Link Unit


EX600-LAB1 EX600-LBB1









Parts Description



Parts Description


Analog Unit






No.	Name	Use
1	Status indication LED	Displays unit status
2	Connector	Connects with input or output devices (SPEEDCON)
3	Marker groove	Can be used to mount a marker
4	Joint bracket	Links units to one another
5	Connector for unit (Plug)	Transmits signals to the neighboring unit and supplies power


IO-Link Unit




No.	Name	Use
1	Status indication LED	Displays unit status
2	Connector	Connects with IO-Link, input, or output devices (SPEEDCON)
3	Marker groove	Can be used to mount a marker
4	Joint bracket	Links units to one another
5	Connector for unit (Plug)	Transmits signals to the neighboring unit and supplies power

End Plate






No.	Name	Use
1	Power connector (PWR IN)	Supplies power to the unit and/or input/ output device (Only the EX600-ED2/ED4/ ED5-□ is SPEEDCON compatible.)
2	Fixing hole for direct mounting	Connects directly to equipment
3	Fixing hole for DIN rail	Converts to manifold or for DIN rail mounting
4	FE terminal	Used for grounding Ground this terminal securely to improve noise immunity.
5	Connector (Unused) Power connector (PWR OUT)	Supplies power to the device on the downstream side




LED Indicator

EX600-SPR EX600-SDN ST(M): Unit diagnostic state ST(M): Unit diagnostic state BF: Communication state 1 C 7 2 \$1 5 1MB NB Q Ø 0,0 000 PWR: Power supply for control and input PWR: Power supply for control and input SF: System state 3 3 PWR(V): Power supply PWR(V): Power supply for output - \overline{O} \overline{O} ÷ for output \$ Æ

EX600-SEN1/SEN2



EX600-SEN3/SEN4(-X80)




Ø


NS: Communication state

MS: Unit state

EX600-SEC




EX600-SPN1/SPN2




Fieldbus System For Input/Output **EX600** Series

LED Indicator




LED Indicator




Fieldbus System For Input/Output **EX600** Series

LED Indicator



EX600 Series Accessories



End Plate Bracket

This bracket is used for the end plate of DIN rail mounting.



EX600-ZMA2

Enclosed parts Round head screw (M4 x 20) 1 pc. P-tight screw (4 x 14) 2 pcs.

EX600-ZMA3 (Specialized for SY series)


Enclosed parts Round head screw with washer (M4 x 20) 1 pc. P-tight screw (4 x 14) 2 pcs.

2 Valve Plate EX600-ZMV1 **EX600-ZMV2** (Specialized for SY series) **Enclosed parts Enclosed parts** Round head screw (M4 x 6) 2 pcs. Round head screw (M4 x 6) 2 pcs. Round head screw (M3 x 8) 4 pcs. Round head screw (M3 x 8) 2 pcs. 33



Send Plate (U side)

The end plate is for use when the manifold valve is not connected.



Round head screw (M4 x 5) 2 pcs.

Reinforcing Brace

This bracket is used on the bottom of the unit at the intermediate position for connecting 6 units or more.

* Be sure to attach this bracket to prevent connection failure between the units caused by deflection.





Seal Cap (10 pcs.)


Be sure to mount a seal cap on any unused I/O connectors. Otherwise, the specified enclosure cannot be maintained.






Marker (1 sheet, 88 pcs.)

The signal name of $\ensuremath{\text{I/O}}$ device and each unit address can be entered and mounted on each unit.






SMC

Accessories **EX600** Series







Connections



Communication Cable




EX9-AC 005 MJ-SSPS (With connector on both sides (Socket/Plug))



EX9-AC 005 MJ-SAPA (With angled connector on both sides (Socket/Plug))


Cab	le length (L)
005	500 mm
010	1000 mm
020	2000 mm
030	3000 mm
050	5000 mm
100	10000 mm

Item		Specifications
Cable O.D.		ø7.7 mm
Conductor nominal Data pair		0.5 mm ² /AWG20
cross section	Drain	0.34 mm ² /AWG22
Wire O.D. (Including insulator)		2.55 mm
Min. bending radius (Fixed)		77 mm





Accessories **EX600** Series




Communication Cable

EX9-AC 005 DN-SSPS (With connector on both sides (Socket/Plug))

• Cable length (L)			
005	500 mm		
010	1000 mm		
020	2000 mm		
030	3000 mm		
050	5000 mm		
100	10000 mm		
100	10000 mm		


Item		Specifications	
Cable O.D.		ø6.7 mm	
Conductor nominal	Power pair	0.34 mm ² /AWG22	
cross section	Data pair	0.25 mm ² /AWG24	
Wire O.D.	Power pair	1.4 mm	
(Including insulator)	Data pair	1.95 mm	
Min. bending radius (Fixed)		67 mm	




EX9-AC 005 DN-SAPA (With angled connector on both sides (Socket/Plug))

• Cable length (L)			
005	500 mm		
010	1000 mm		
020	2000 mm		
030	3000 mm		
050	5000 mm		
100	10000 mm		


Item		Specifications	
Cable O.D.		ø6.7 mm	
Conductor nominal	Power pair	0.34 mm ² /AWG22	
cross section	Data pair	0.25 mm ² /AWG24	
Wire O.D.	Power pair	1.4 mm	
(Including insulator)	Data pair	1.95 mm	
Min. bending radius (Fixed)		67 mm	



Communication Cable




Communication Cable



Connections (Straight cable)

Pield-wireable Communication Connector




I/O Cable with Connector, I/O Connector

For details, refer to the Web Catalog


To details, refer to the web catalog.			
Name	Use	Part no.	Description
Cable with	Cable with For sensor		Cable with M12 connector (4 pins/3 m)
connector		PCA-1557772	Cable with M8 connector (3 pins/3 m)
	Field-wireable connector	PCA-1557730	Field-wireable connector (M8/3 pins/Plug/Piercecon® connection)
For sensor		PCA-1557743	Field-wireable connector
	SHALL SHALL	PCA-1557756	(M12/4 pins/Plug/QUICKON-ONE connection/SPEEDCON)
Y connector	For sensor	PCA-1557785	Y connector (2 x M12 (5 pins)-M12 (5 pins)/SPEEDCON)
		PCA-1557798	Y connector (2 x M8 (3 pins)-M12 (4 pins)/SPEEDCON)

* When using the Y connector, connect it to the connector on the I/O unit through the sensor cable (PCA-1557769) with the M12 connector.




For IO-Link Unit

EX9-AC 005 -SSPS (With connector on both sides (Socket/Plug))




I/O Cable with Connector, I/O Connector



5 Ö

(IO-Link Device Tool License Key

USB dongle EX9-ZSW-LDT1



SMC

EX600 Series Made to Order Please contact SMC for detailed specifications and lead times.

Made to Order


SI Unit


Prepare the SI unit, each type of unit, and the manifold valve (without SI unit) separately, and combine them before use.


① Ethernet POWERLINK compatible EX600-SPL1-X26

• Dimensions are the same as those of the EX600-SEN3.

③CC-Link IE Field compatible EX600-SCF1-X60








2 Modbus/TCP compatible EX600-SMT1-X25

• Dimensions are the same as those of the EX600-SEN3.

Communication Cable



White: CAN H

Blue: CAN L

Wire O.D.

(Including insulator) Data pair

Min. bending radius (Fixed)

1.4 mm

2.05 mm

67 mm

Power pair

4

5

Socket connector

pin arrangement A-coded (Normal key)



EX600 Series **Specific Product Precautions**

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For fieldbus system precautions, refer to the "Operation Manual" on the SMC website: https://www.smcworld.com

Mounting

A Caution

- 1. When handling and assembling units, do not touch the sharp metal parts of the connector or plug.
- 2. When connecting six stations or more, be sure to use the intermediate reinforcing brace (EX600-ZMB1 or EX600-ZMB2).

Operating Environment

A Caution

1. Select the proper type of enclosure according to the operating environment.

IP65/67 is achieved when the following conditions are met.

- 1) Provide appropriate wiring between all units using electrical wiring cables, communication connectors and cables with M12 connectors.
- 2) Appropriately mount each unit and valve manifold.
- 3) Be sure to mount a seal cap on any unused connectors.

If using in an environment that is exposed to water splashes, please take measures such as using a cover.

When the enclosure is IP40, do not use in an operating environment or atmosphere where it may come in contact with corrosive gas, chemical agents, seawater, water, or water vapor. When connected to the EX600-D $\Box\Box$ E or EX600-D $\Box\Box$ F, manifold enclosure is IP40.

Also, the handheld terminal conforms to IP20, so prevent foreign matter from entering inside, and water, solvent or oil from coming in direct contact with it.

Adjustment / Operation

▲Warning

<Handheld Terminal>

1. Do not apply pressure to the LCD.

There is a possibility of the crack of LCD and injuring.

2. The forced input/output function is used to change the signal status forcibly. When operating this function, be sure to check the safety of the surroundings and installation.

This may cause injuries or equipment damage.

3. Incorrect setting of parameters can cause a malfunction. Be sure to check the settings before use

This may cause injuries or equipment damage.

A Caution

<Handheld Terminal>


1. Do not press the setting buttons with a sharp pointed object.

This may cause damage or equipment failure.

2. Do not apply excessive load and impact to the setting buttons.

This may cause damage, equipment failure or malfunction.

When the order does not include the SI unit, a valve plate which connects the manifold and SI unit, is not mounted. Use attached valve holding screws and mount the valve plate. (Tightening torque: 0.6 to 0.7 N·m)



Trademark

DeviceNet® is a registered trademark of ODVA, Inc. EtherNet/IP[®] is a registered trademark of ODVA, Inc.

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany. Modbus® is a registered trademark of Schneider Electric, licensed to the Modbus Organization, Inc. QuickConnect[™] is a trademark of ODVA.



▲ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "**Caution**," "**Warning**" or "**Danger**." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)^{*1}, and other safety regulations.

- Caution: indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.
- Warning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

AWarning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
 - The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.

- 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
- 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
- 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
- 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

- *1) ISO 4414: Pneumatic fluid power General rules relating to systems.
 - ISO 4413: Hydraulic fluid power General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)
 - ISO 10218-1: Manipulating industrial robots Safety. etc.

 The product is provided for use in manufacturing industries. The product herein described is basically provided for peaceful use in manufacturing industries. If considering using the product in other industries, consult SMC beforehand

and exchange specifications or a contract if necessary. If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
 - 2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

History
* SY7000 series valves have been added as applicable solenoid valves. TS
Edition F * The IO-Link unit has been added.
* JSY series valves have been added as connectable valves.
* The "How to Order" and "Dimensions" pages of the connectable valves have been deleted.
* An end plate (D side) and M12 (4/5 pins) A-coded power supply connectors have been added.
* Number of pages has been decreased from 68 to 48. YT
Edition G * An IO-Link unit compatible SI unit has been added (PROFINET). ZR

A Safety Instructions Be sure to read the "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" before use.

SMC Corporation Akihabara UDX 15F,

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 Fax: 03-5298-5362 https://www.smcworld.com © 2021 SMC Corporation All Rights Reserved

Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.

Fieldbus System




(For Input/Output)

Supports digital inputs/outputs, analog inputs/outputs, and IO-Link units

New


An **O IO**-Link unit compatible SI unit has been added (EtherNet/IPTM).






EX600 Series

SI Unit Model Indication and How to Order



Summary of Product parts



No.	Description	Function	
1	Status display LED	Displays the status of the unit.	
2	Display cover	Open when making the switch settings	
3	Display cover screw	Loosen the screw to open the display cover.	
4	Communication connector (PORT 2)	Connection for the cable for fieldbus outputs.	
5	Marker groove	Groove to mount a marker.	
6	Valve plate mounting screw hole	Hole for mounting the valve plate.	
7	Valve plate mounting groove	Groove to insert the valve plate into.	
8	Joint bracket	Bracket for joining to adjacent units.	
9	Unit connector (plug)	Transmits signals and power supplies to adjacent units.	
10	Communication connector (PORT 1)	Connection for the cable for fieldbus inputs.	
12	Seal cap (1 pc.)	Mounted on to unused connectors (PORT 2).	

Specifications

Мос	el	EX600-SEN7	EX600-SEN8		
	Number of ports	2 pc	orts		
	Protocol	EtherNet/IP™ (Conformance version: Composite18)			
	Transmission speed	10/100 Mbps			
	Transmission type	Full duplex/Half duplex			
_	Configuration file	EDS file			
nication	Occupying area (Number of input/output)	(1212 bytes/1210 bytes) Max.			
Communication	IP address range	By switch on SI unit: 192.168.0 or 1.1 to 254 Via DHCP server: Any address			
0	Device information	Device Type: 12 (Cor	Vendor ID: 7 (SMC Corporation) Device Type: 12 (Communication Adapter) Product code: 258		
	Applicable function	Quickconnect [™] DLR Web server			
	nal current consumption ver supply for control / input)	120 mA or less			
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)		
out	Number of solenoid valves	32 outputs			
Valve output	Applicable valve series	Solenoid valve with surge voltage suppressor of 24 VDC and 1.0 W or less (manufactured by SMC)			
Val	Fail safe	HOLD/CLEAR / Force ON			
	Protection	Short circui	t protection		
	Enclosure	IP67 (manifold assembled) *1			
	Operating temperature range	-10 to 50 °C			
	Storage temperature range	-20 to 60 °C			
	Operating humidity range	35 to 85% RH (n	35 to 85% RH (no condensation)		
ient	Withstand voltage	500 VAC for 1 minute between external terminals and FE			
ũu	Insulation resistance	500 VDC, 10 M Ω or more between external terminals and FE			
Environm	Vibration resistance	10 to 57 Hz: constant amplitude 0.75 mm p-p 57 to 150 Hz: constant acceleration 49 m/s ² for 2 hours in each direction X, Y and Z respectively (De-energized)			
	Impact resistance	147 m/s ² 3 times in each directions of X, Y and Z respectively (De-energized)			
Star	ndard	CE/UKCA marked, UL (CSA)			
Wei	ght	300) g		

*1: All unused connectors must have a seal cap fitted to maintain IP67 rating.

Dimensions

